











PACI-360AMX-UPC32-ACCY01
Accessory Kit

Part #	Description	Qty	
PACI-AMX-USB DRIVE	Manuals for UPC32/UPC12 AMX and UPC Suite (Software)	1	
PACI-P20	P20 Dummy Connector Dummy Plug for Magnetics Interface	1	
GENE-PC-10/4-120/208V30A	Power Cord with 120/208V 30A plug (NEMA L21-30P)	1	
PACI-UPC32-QUICK	Quick Reference Sheet for UPC Series	1	







PACI-360AMX-UPC32-ACCY02
Accessory Kit

Part #	Description	Qty	
PACI-AMX-USB DRIVE	Manuals for UPC32/UPC12 AMX and UPC Suite (Software)	1	
PACI-134193	Opt M5283 Paralleling Y Cable	1	
GENE-PC-10/4-120/208V30A	Power Cord w 120/208V no Plug	1	
PACI-UPC32-QUICK	Quick Reference Sheet for UPC Series	1	



PACI-360AMX-UPC32-PKG01-ACCY01
Accessory Kit

Part #	Description	Qty	
PACI-133620	Operation Manual for UPC12 and 32 on CD	1	
PACI-139250	Operation Manual for AMX Series on CD	1	
GENE-PC-10/4-120/208V30A	Power Cord with 120/208V 30A plug (NEMA L21-30P)	1	
PACI-UPC32-QUICK	Quick Reference Sheet for UPC Series	1	
PACI-UPCSUITE	Edition 6, Software (v3.0), Firmware (v5.22) Pacific Power UPC Suite	1	