

YOKO-WT3000-PKG07-ACCY01
 Accessory Kit

Part #	Description	Qty	
YOKO-1066-2	Input adapter, safety banana red	4	
YOKO-WT3000-USB Drive	User's Manual, Vol. 1,2, and 3 for WT3000, USB Flash Drive	1	
YOKO-B9318FX	Input cover with 4 screws (installed)	1	
YOKO-HEX	Hex key	1	
GENE-PC-5-15A	Power Cord 120V 15A	1	
YOKO-1066-0	Input adapter, safety banana black	4	

YOKO-WT3000-PKG07-ACCY01
Accessory Kit

	Description	Qty	