




| Part #          | Description                       | Qty |                                                                                       |
|-----------------|-----------------------------------|-----|---------------------------------------------------------------------------------------|
| FUJI-ACC-14     | AC Power Cord                     | 1   |    |
| FUJI-CT30       | Cleaver w/case and instructions   | 1   |    |
| FUJI-Q-19/70S-E | Quick Reference Guide for FSM-70S | 1   |   |
| FUJI-DCC-18     | Cable, battery Charger            | 1   |  |
| FUJI-BTR-09     | Battery Pack                      | 1   |  |
| FUJI-SL-01      | Sleeve Loader                     | 1   |  |

| Part #      | Description                                                 | Qty |                                                                                       |
|-------------|-------------------------------------------------------------|-----|---------------------------------------------------------------------------------------|
| FUJI-USB-01 | USB Cable, A to Mini B                                      | 1   |    |
| FUJI-M-70   | Instruction Manual for FSM-70S<br>(Paper, CD, or USB Drive) | 1   |    |
| FUJI-W-70-E | Warning and Caution Sheet                                   | 1   |   |
| FUJI-CC-30  | Hard Carry Case with Strap                                  | 1   |  |
| FUJI-ADC-18 | AC Adapter/Battery Charger                                  | 1   |  |
| CLEA-CT811  | Optical Cleaning Pad                                        | 5   |  |

| Part #            | Description                                                        | Qty |                                                                                       |
|-------------------|--------------------------------------------------------------------|-----|---------------------------------------------------------------------------------------|
| FUJI-FSM-70S-WT01 | Work Tray (2 pc., Base and Handle)                                 | 1   |    |
| FUJI-ELCT2-20A    | Electrode set (qty. 2) for FSM-17                                  | 1   |    |
| FUJI-CLAMP-S70C   | Sheath Clamp, (installed)<br>100 to 3000 um diameter               | 2   |   |
| FUJI-CLAMP-S70D   | Sheath Clamp, 900 im diameter<br>loose tube fiber (5-16 mm cleave) | 2   |  |
|                   |                                                                    |     |                                                                                       |
|                   |                                                                    |     |                                                                                       |