


Part #	Description	Qty	
FUJI-ACC-14	AC Power Cord	1	
FUJI-CT30	Cleaver w/case and instructions	1	
FUJI-Q-19/70S-E	Quick Reference Guide for FSM-70S (USB)	1	
FUJI-DCC-18	Cable, battery Charger	1	
FUJI-BTR-09	Battery Pack	1	
FUJI-SL-01	Sleeve Loader	1	

Part #	Description	Qty	
FUJI-USB-01	USB Cable, A to Mini B	1	
FUJI-M-70	Instruction Manual for FSM-70S (Paper, CD, or USB Drive)	1	
FUJI-W-70-E	Warning and Caution Sheet (USB)	1	
FUJI-CC-30	Hard Carry Case with Strap	1	
FUJI-ADC-18	AC Adapter/Battery Charger	1	
FUJI-CLEA-CT811	Optical Cleaning Pad	5	

Part #	Description	Qty	
FUJI-FSM-70S-WT01	Work Tray (2 pc., Base and Handle)	1	
FUJI-DCC-11	Power Cord for HJS-02/03	1	
FUJI-HJS-02-NR	Hot jacket stripper	1	
FUJI-FH-50-12	Fiber Holder, for 12 Ribbon	2	
FUJI-S014397-CASE01	Cleaning Kit Carrying Case	1	
FUJI-S014397-CLEANING-FLUID01	FCC2 Fiber Connector Cleaner and Preparation Fluid	1	

Part #	Description	Qty	
FUJI-S014397-COTTON -SWAB01	Lint-free Cotton Swabs	50	
FUJI-S014397-PEN LIGHT01	LED Pen Light	1	
FUJI-S014397-SCRUBBER -BRUSH01	Scrubber Brush with Stiff Tapered Nylon Bristles	1	
FUJI-S014397-SWEEPER -BRUSH01	Sweeper Brush with Soft Nylon Bristles	1	
FUJI-S014397-INST -SHEET01	Instruction Sheet with Illustrations (USB)	1	