

BLU SERIES

Battery Load Units

- Lightweight starting from 12,8 kg (28.2 lbs)
- Powerful discharge power of up to 28,4 kW
- Voltage measurement range: up to 480 V DC
- Discharge current up to 340 A DC
- Easily expandable for larger banks using BXL extra load units
- Current probe measurement range: 0 – 300 / 1000 A DC
- User adjustable alarm and shutdown parameters for preventing excessive discharge
- Detailed test analysis using DV-B Win software
- Test resume feature in case of interrupted power supply



Description

Batteries are crucial part to the overall reliability of a substation. During the power outage many electric power objects/systems, such as power plants and generator excitation systems, should continue operating using batteries. Inability of a battery string to provide а sufficient voltage/power supply to protection circuits may lead to catastrophic consequences to the substation equipment. Therefore, it is necessary batteries to be inspected regularly in order to monitor their condition and maximize their lifetime. The essential and most reliable test for a condition assessment of a battery health is the capacity measurement test. The best way to measure battery capacity is to perform a discharge test.

The Battery Load Units - BLU series are standalone or PC-controlled battery capacity test set, based on a state-of-the-art technology, using the most advanced power electronics solutions with coolers and fans integrated into device. The BLU series devices are lightweight solution for the test engineers from all around the world, developed to meet customer's wide ranging test procedures (standardized as well as customized). Using a BLU device, the capacity test is performed in an accurate, user-friendly way in accordance to actual standards for battery testing (IEEE 450-2010 / 1188-2005 / 1106-2015, IEC 60896-11/22 and other relevant standards).

Discharging can be performed at constant current, constant power, constant resistance or in accordance with a pre-selected load profile. The discharge test can be conducted even in case a battery remains connected to the load – by measuring and taking into account the load current during the process.

The BLU series devices provide the discharge current of up to 340 A and are applicable to up to 480 V battery strings.



When a required discharge current or power exceeds the capacity of a single BLU device, up to 10 BLU devices can be connected in parallel. Alternatively, External Load Units BXL series can also be used to increase discharging capacity. Combined with Battery Voltage Supervisor BVS and Battery Voltage Recorders BVR, BLU series devices are powerful tool which enables performing detailed evaluation of batteries. Overview of the maximum currents for various battery voltage ranges with the minimum achievable cell voltage of 1,75 V is presented in the table below. Maximum currents available by using BXL series devices are also presented in the table.

		Maximum discharge current (A)								
Battery voltage (V)		BLU100A	BLU200A	BLU340A	BXL-A	BLU220T	BXL-T	BLU360V	BXL-V	
NOM.										
6	5,25	40	50	50	59	100	74	50	11	
	7,05				80		100		15	
12	10,5	80	100	100	119	200	156	100	26	
12	14,1	00	100	100	160	100	210	100	35	
24	21,0	160	200	160	186	340	312	160	55	
24	28,2	100	200	100	250	540	420	100	75	
40	42,0	100	200	160	186	340	312	160	115	
40	56,4	160	200	160	250		420		155	
	52,5	120	120	160	81	275	260	160	141	
60	70,5				110		350		190	
	96,3	440		400	119		-	160	96	
110	129,3	110	120	160	160	-			130	
400	105,0	400	400	450	134			150	107	
120	141,0	100	120	150	180	-			145	
	192,5			440	67			110	85	
220	258,5	55	/5	110	90	-	-		115	
	210,0				67				93	
240	282,0	50	70	100	90	-	-	100	125	
	300,0								34	
480	480,0	1 -	1 -	-	-		-		50	55
Weight (kg / lbs)		12,8 / 28.2	14,5 / 32	20,6 / 45.4	12,5 / 28	15,1 / 33	12,5 / 28	20,6 / 45.4	16 / 35	
Max Power (kW)		14,2	19,7	28,4	25,4	19,4	24,7	28,4	35	



Application

Typical application is measuring the capacity and full voltage of the batteries that serve as a backup power supply in (but not limited to):

- Power plants
- Telecommunication systems
- Generator excitation systems
- Substations
- Protection and control systems

Connecting BLU to Battery

Single mode

The BLU device can be connected to any battery test object by using a set of current cables and, optionally, a set of voltage sense cables. To maximize the accuracy and measurement repeatability, all clamps must have good connection to the battery terminals while any crossing between the cables should be avoided. The BLU displays an appropriate message if connection between a cable clamp and the corresponding battery terminal is not established.

Parallel discharge test mode

In case the required discharge current or power exceeds the capacity of a single BLU device, several (up to ten) devices can be connected in parallel.

Connection between BLU devices is established bv using Ethernet ports and **RS485** communication. The communication is based on a MASTER-SLAVE principle - arbitrary selected device is set as MASTER while all the other BLU devices should be set as SLAVE units. In the parallel connection the MASTER will discharge as much energy as possible; the remaining energy (discharge current / discharge power) will be discharged on the first SLAVE unit in a chaine. If MASTER and the first SLAVE does not have capacity to cover the discharge requirements, the remaining energy will be discharged on the next SLAVE in a chain, etc.







Current Probe mode

In case the battery has to remain connected to the load, or an Extra Load BXL needs to be connected due to increase in discharge power, the discharge test needs to be carried out using the Current Probe CP MODE. In this mode the measurement will be based either on the total battery current or a load current being measured by the DC current probe. The current probe connection point, for both modes, are illustrated in the figures below.



Benefits and Features

The list of the instruments application, benefits and features includes:

- Battery capacity measurement by conducting a discharge test, in compliance with corresponding IEEE, IEC and other relevant standards
- Constant I, Constant P and Constant R operation modes
- Several Load profile operation modes: *Load profile I, Load profile P* and *Load profile R*, enable simulating load characteristics variation during a discharge test
- Parallel operation feature (not provided for the BLU100A model)
- Current probe mode enables conducting discharging test while a load remains connected or when BXL units are used
- Test settings can be modified during the test
- Adjustable alarm and shutdown parameters for preventing excessive discharge
- If supported by a Battery Voltage Recorder BVR Series, additional features of cell voltage and cell temperature measurement are available
- Battery internal resistance measurement in combination with Battery Voltage Supervisor (BVS) according to IEC 60896



2 - Keyboard - used for 1 - Display - 4.3" color touch controlling and operating screen display the instrument 4 - External input (EXT IN) and external output (EXT OUT) used for BLU-BLU parallel 5 - Current probe - measuring operation (not available for load current using the external BLU100A model) V current probe. 3 - Flash drive - used for transferring BLU memory data into an external memory stick + SBC / firmware upgrade 6 - Emergency STOP button used when unexpected or unwanted action occurs. 7 - Interface - enables controlling the BLU from a PC and downloading previously recorded results. Dv/power 6 Battery Load Unit BLU series 8 - Alarm output - used for triggering external alarm 9 - Current and Voltage buzzer. terminals - current and OLTAGE SENS voltage test cable terminals 11 - Protective Earth 10 - External Load trigger -Connector - protective earth used for triggering BXL connector used to connect to external load units protective ground (PE)

Combining BLU and BVR Series

Battery Voltage Recorder Series (BVR11 and BVR20 models) are lightweight, user-friendly, rechargeable handheld devices intended for individual battery cell voltage and temperature measurement while the battery is either in online or offline mode. When used in combination with the BLU device it serves as an efficient supplement to the battery capacity testing. Options and features, including the main differences between BVR11 and BVR20

models, are presented in the table below.

	BVR11	BVR20
CELL VOLTAGE MEASUREMENT	•	•
STRING VOLTAGE MEASUREMENT	•	0
AMBIENT TEMPERATURE MEASUREMENT	•	•
ELECTROLYTE TEMPERATURE MEASUREMENT	0	•
VOLTAGE MEA SUREMENT RANGE	± 500 V DC ± 30 V DC	± 2,35 V DC ± 7 V DC ± 30 V DC
USB COMMUNICATION WITH PC	•	•
BLUETOOTH COMMUNICATION WITH PC	•	0
RFID CELL RECOGNITION	0	•
COMMUNICATION WITH EXTERNAL DENSITIY METER	0	•



Combining BLU and BVS

Battery Voltage Supervisor Capacity Model (BVS-CM) is a battery voltage monitoring system for real time data gathering and presentation. It contains of up to 128 individual BVS Modules (CVM-C), and the Control Unit (BVS CU). Power supply for each module (BVS M) is provided from the Control Unit (BCM-CU). BVS identifies potential battery malfunction by continuously monitoring cell voltage, intercell voltage, and ambient temperature during the discharge test.

The device is used during a battery charging / discharging process. When used in а combination with the BLU device it serves as an efficient supplement to battery capacity testing. BVS Additional feature available in а combination with the BLU Series is a battery internal resistance measurement.

DV-B Win Software

The DV-B Win software is included in the purchase price, and all its updates are free of charge. Using the DV-B Win software a test can be performed and observed from a PC, and the results can be saved directly on a PC. Communication between the BLU and a PC is achieved through a USB cable. Using DV-B Win the results can be arranged and printed for a report in a selectable format as



an XLS, PDF, Word, or RTF format. Also, the possibility of importing other types of data format (jpg, png, doc) into standardized DV-B Win report is provided, as well as exporting the numerical and graphical results from DV-B Win into customizable report. Additionally, the software provides a possibility of setting extra parameters (cell voltage, string voltage, capacity and time) for alarming and ending the test.





BLU Series - models

BLU100A

	•	weight – 12,8 kg (28.2 lbs)
	•	discharge current – up to 160 A
	•	designed for 6 V – 300 V DC battery systems

BLU200A

I AND	•	weight – 14,5 kg (32 lbs)
	•	discharge power – up to 19,7 kW
	•	discharge current – up to 200 A
	•	designed for 6 V – 300 V DC battery systems

BLU340A

•	weight – 20,6 kg (45.4 lbs)
•	discharge power – up to 28,4 kW
•	discharge current – up to 160 A
•	designed for 6 V – 300 V DC battery systems

BLU220T

•	weight – 15,1 kg (33 lbs) discharge power – up to 19,4 kW
•	discharge current – up to 340 A
•	designed for 6 V – 60 V DC battery systems

BLU360V

	•	weight – 20,6 kg (45.4 lbs)
	•	discharge power – up to 28,4 kW
	•	discharge current – up to 160 A
	•	designed for 6 V – 480 V DC battery systems



Technical Data

Mains Power Supply

- Connection according to IEC/EN60320-1; C320
- Voltage:
 90 V 264 V AC, 50 / 60 Hz, single-phase
- Input power: 200 VA
- Fuse 2 A / 250 V, type F

Dimensions and Weights

Model		Dimensions	Weight
BLU100A	Instrument	440 x 221 x 355 mm 17.3 x 8.7 x 14 in	12,8 kg 28.2 lbs.
(without acc.)	Canvas Transport case *	570 x 310 x 415 mm 22.4 x 12.2 x 16.3 in	3,6 kg 7.9 lbs.
	Instrument	560 x 221 x 355 mm 22 x 8.7 x 14 in	14,5 kg 32 lbs.
BLU200A (without acc.)	Transport case *	665 x 300 x 418 mm 26.2 x 11.8 x 16.5 in	8,5 kg 18.7 lbs
	Canvas Transport case **	690 x 310 x 415 mm 27.2 x 12.2 x 16.3 in	3,7 kg 8.2 lbs.
	Instrument	560 x 221 x 355 mm 22 x 8.7 x 14 in	15,1 kg 33.2 lbs.
BLU220T (without acc.)	Transport case *	665 x 300 x 418 mm 26.2 x 11.8 x 16.5 in	8,5 kg 18.7 lbs.
	Canvas Transport case **	690 x 310 x 415 mm 27.2 x 12.2 x 16.3 in	3,7 kg 8.2 lbs.
BLU340A	Instrument	730 x 221 x 355 mm 28.7 x 8.7 x 14 in	20,6 kg 45.4 lbs.
acc.)	Transport case *	795 x 290 x 415 mm 31.3 x 11.4 x 16.3 in	10,1 kg 22.3 lbs.
BLU360V	Instrument	730 x 221 x 355 mm 28.7 x 8.7 x 14 in	20,6 kg 45.4 lbs.
acc.)	Transport case *	795 x 290 x 415 mm 31.3 x 11.4 x 16.3 in	10,1 kg 22.3 lbs.

* Included instrument transport case

** Optional instrument transport case

Display

Size

• 4,3 inch color screen display

Range / Resolution

- Current: 0 2 999,9 A DC / 0,1 A
- Voltage: 0 999,9 V DC / 0,1 V
- Capacity: 0 9999,9999 Ah / 0,0001 Ah
- Time: 00h:00m:00s 99h:59m:59s / 1 sec

Measurement

Internal voltage measurement

Model	Range	Resolution
BLU100A	0 – 300 V DC	0,1 V
BLU200A	0 – 300 V DC	0,1 V
BLU340A	0 – 300 V DC	0,1 V
BLU220T	0 – 75 V DC	0,1 V
BLU360V	0-480 V DC	0,1 V

• Typical accuracy: ± 0,5% of reading ± 0,1 V

Internal current measurement

Model	Range	Resolution
BLU100A	0 – 300 A DC	0,1 A
BLU200A	0 – 300 A DC	0,1 A
BLU340A	0 – 300 A DC	0,1 A
BLU360V	0 – 300 A DC	0,1 A
BLU220T	0 – 400 A DC	0,1 A

• Typical accuracy: ± 0,5 % of reading ± 0,2 A

Maximum discharge current & power

Model	Current	Power
BLU100A	160 A	14,2 kW
BLU200A	200 A	19,7 kW
BLU340A	160 A	28,4 kW
BLU220T	340 A	19,4 kW
BLU360V*	160 A	28,4 kW

 * For the BLU360V model only, maximum power derates at temperatures over +35°C (+95°F).

Current / voltage diagram for the BLU360V model at +35 $^{\circ}C$ (+95 $^{\circ}F) and +50<math display="inline">^{\circ}C$ (+122 $^{\circ}F) is presented below.$





Current probe range and resolution

- Range: 0 300 / 1 000 A DC
- Resolution: 0,1 A DC

Time measurement

- Typical accuracy:
 - ± 0,1 % of reading ± 1 sec

Environment conditions

- Operating temperature:
 -10 °C to +50 °C / 14 °F to +122 °F
- Storage & Transportation temperature: -40 °C to +70 °C / -40 °F to +158 °F
- Relative humidity: 90%, non condensing
- Pollution degree: 2

Warranty

3 years

Applicable Standards

- IEEE 450-2010, IEEE 1188-2005, IEEE 1106-2015, IEC 60896-11, IEC 60896-22 and other relevant standards
- Installation/overvoltage: category II
- Safety
 - Low Voltage Directive: Directive 2014/35/EU (CE conform) Applicable standards, for a class I instrument, pollution degree 2, Installation category II: IEC EN 61010-1
- Electromagnetic Compatibility:
 Directive 2014/30/EU (CE conform) Applicable standard: EN 61326-1
- CAN/CSA-C22.2 No. 61010-1

All specifications herein are valid at ambient temperature of + 25 $^{\circ}$ C /+ 77 $^{\circ}$ F and recommended accessories. Specifications are subject to change without notice.

Accessories





Order Info

Instrument	Article No
Battery Load Unit BLU100A	BLU100A-N-00
Battery Load Unit BLU200A	BLU200A-N-00
Battery Load Unit BLU220T	BLU220T-N-00
Battery Load Unit BLU340A	BLU340A-N-00
Battery Load Unit BLU360V	BLU360V-N-00

Included Accessories	Article No	
Windows based DV-B Win PC software including USB cable		
Mains Power cable	MPCXXA-XX-00	
Ground (PE) cable	CABLE-GND-00	
Canvas transport case		
(for BLU100A model)	HARD-CASE-DZ	
Transport case		
(for BLU200A and BLU220T models)		
Transport case		
(for BLU340A and BLU360V models)		

Recommended	Article No
Current cables 2 x 3 m 35 mm ² (9.84 ft, 2 AWG) with alligator clamps (A4) isolated (<i>for BLU100A, BLU200A, BLU340A and BLU360V models</i>)	C2-03-35VA4I
Current cables 2 x 3 m 50 mm ² (9.84 ft, 0 AWG) with alligator clamps (A4) isolated (<i>for BLU220T</i>)	C2-03-50FA4I
Cable bag	CABLE-BAG-00

Optional	Article No
Battery External Load Unit BXL-A	BXL400X-A-00
Battery External Load Unit BXL-T	BXL400X-T-00
Battery External Load Unit BXL-V	BXL400X-V-00
Cable set 2 x 2 m 1 mm ² (6.56 ft, 17 AWG) for parallel operation (<i>for BXL models</i>)	PO-02-01BPBP
Battery Voltage recorder BVR11 with accessories	BVR11X-NN-00
Battery Voltage recorder BVR20 with accessories	BVR20X-NN-00
Current cables 2 x 3 m 50 mm ² (9.84 ft, 0 AWG) with alligator clamps (A4) isolated (<i>for BLU100A, BLU200A, BLU340A, BLU360V, BXL-A and BXL-V models</i>)	C2-03-50VA4I
Current cables 2 x 5 m 35 mm ² (16.4 ft, 2 AWG) with alligator clamps (A4) isolated (<i>for BLU100A, BLU200A, BLU340A, BLU360V, BXL-A and BXL-V models</i>)	C2-05-35VA4I
Current cables 2 x 5 m 50 mm ² (16.4 ft, 0 AWG) with alligator clamps (A4) isolated (<i>for BLU100A, BLU200A, BLU340A, BLU360V, BXL-A and BXL-V models</i>)	C2-05-50VA4I
Current cables 2 x 5 m 70 mm ² (16.4 ft, 00 AWG) with alligator clamps (A4) isolated (<i>for BLU220T and BXL-T models</i>)	C2-05-70FA4I
Current cables 2 x 10 m 35 mm ² (32.8 ft, 2 AWG) with alligator clamps (A4) isolated (<i>for BLU100A, BLU200A, BLU340A, BLU360V and BXL models</i>)	C2-10-35VA4I
Current cables 2 x 10 m 50 mm ² (32.8 ft, 0 AWG) with alligator clamps (A4) isolated (<i>for BLU100A, BLU200A, BLU340A, BLU360V, BXL-A and BXL-V models</i>)	C2-10-50VA4I



Current cables 2 x 10 m 70 mm ² (32.8 ft, 00 AWG) with alligator clamps (A4) isolated (<i>for BLU220T and BXL-T models</i>)	C2-10-70FA4I
Current cables 2 x 15 m 50 mm ² (49.2 ft, 0 AWG) with alligator clamps (A4) isolated (<i>for BLU100A, BLU200A, BLU340A, BLU360V, BXL-A and BXL-V models</i>)	C2-15-50VA4I
Current cables 2 x 20 m 50 mm ² (65.6 ft, 0 AWG) with alligator clamps (A4) isolated (<i>for BLU100A, BLU200A, BLU340A, BLU360V, BXL-A and BXL-V models</i>)	C2-20-50VA4I
Extension cables 2 x 5 m 35 mm ² (16.4 ft, 2 AWG) (for BLU100A, BLU200A, BLU340A, BLU360V and BXL models)	E2-05-35VA3I
Extension cables 2 x 5 m 70 mm ² (16.4 ft, 00 AWG) (<i>for BLU220T and BXL-T models</i>)	E2-05-70VFMI
Extension cables 2 x 10 m 35 mm ² (32.8 ft, 2 AWG) (<i>for BLU100A, BLU200A, BLU340A, BLU360V and BXL models</i>)	E2-10-35VA3I
Extension cables 2 x 10 m 50 mm ² (32.8 ft, 0 AWG) (<i>for BLU100A, BLU200A, BLU340A, BLU360V and BXL models</i>)	E2-10-50VA3I
Sense cables 2 x 3 m (9.84 ft) with banana plugs + dolphin clip (<i>for BLU models</i>)	S2-03-00BPDC
Sense cables 2 x 5 m (16.4 ft) with banana plugs + dolphin clip (<i>for BLU models</i>)	S2-05-00BPDC
Sense cables 2 x 10 m (32.8 ft) with banana plugs + dolphin clip (<i>for BLU models</i>)	S2-10-00BPDC
Sense cables 2 x 15 m (49.2 ft) with banana plugs + dolphin clip (<i>for BLU models</i>)	S2-15-00BPDC
Sense cables 2 x 20 m (65.6 ft) with banana plugs + dolphin clip (<i>for BLU models</i>)	S2-20-00BPDC
Current clamp 30/300 A power supplied from the instrument with extension 5 m (16.4 ft) (for BLU models)	CACL-0300-06
Cable for external alarm (<i>for BLU models</i>)	CABLE-EXA-05
Extension cable for external alarm 5 m (16.4 ft) (for BLU models)	E1-EXABLU-05
Cable for parallel operation 3 m (9.84 ft) (for BLU200A, BLU220T, BLU340A and BLU360V models)	CP-03RJ45-00
Cable set 2 x 5 m 1 mm ² (16.4 ft, 17 AWG) for parallel operation (<i>for BXL models</i>)	PO-05-01BPBP
Canvas transport case (for BLU200A and BLU220T models)	HARD-CASE-B3



Order Examples

BLU200A with recommended accessories

Instrument with Included Accessories	Quantity	Article No
Battery Load Unit BLU200A	1 set	BLU200A-N-00
- Mains power cable		
- USB with DV-B Win PC software		
- USB cable		
- Ground (PE) cable		
- Transport case		
Recommended Accessories		
Current cables 2 x 3 m 35 mm ² (9.84 ft, 2 AWG) with alligator clamps (A4) isolated	1 pc	C2-03-35VA4I
Cable bag	1 pc	CABLE-BAG-00

BLU340A + BXL-A with recommended accessories

Instruments with Included Accessories	Quantity	Article No
Battery Load Unit BLU340A	1 pc	BLU340A-N-00
Battery Extra Load Unit BXL-A	1 pc	BXL400X-A-00
- USB with DV-B Win PC software	1 pc	
- USB cable	1 pc	
- Mains power cable	2 pcs	
- Ground (PE) cable	2 pcs	
- Transport case	2 pcs	
Recommended Accessories		
Current cables 2 x 3 m 35 mm ² (9.84 ft, 2 AWG) with alligator clamps (A4) isolated	2 pcs	C2-03-35VA4I
Cable bag	2 pcs	CABLE-BAG-00
Current clamp 30/300 A power supplied from the instrument with extension 5 m (16.4 ft)	1 pc	CACL-0300-06

2 x BLU360V with recommended accessories

Instruments with Included Accessories	Quantity	Article No
Battery Load Unit BLU360V	2 sets	BLU360V-N-00
- Mains power cable		
- USB with DV-B Win PC software		
- USB cable		
- Ground (PE) cable		
- Transport case		
Recommended Accessories		
Current cables 2 x 3 m 35 mm ² (9.84 ft, 2 AWG) with alligator clamps (A4) isolated	2 pcs	C2-03-35VA4I
Cable bag	2 pcs	CABLE-BAG-00
Cable for parallel operation 3 m (9.84 ft)	1 pc	CP-03RJ45-00

IBEKO Power AB Stockholmsvägen 18

181 50 Lidingö, Sweden

Contact

Phone: +46 70 0925 000 E-mail: sales@dv-power.com