# TORKEL 840/860 Battery Load Units



## **TORKEL 840/860**



## Battery load units

Batteries in power plants and transformer substations must provide the equipment they serve with standby power in the event of a power failure. Unfortunately, however, the capacity of such batteries can drop significantly for a number of reasons before their calculated life expectancy is reached. This is why it is so important to check batteries at regular intervals, and the only reliable way of measuring battery capacity is to conduct a discharge test.

TORKEL™ 840 - UTILITY is used for battery systems ranging from 12 to 250 V – often encountered in switchgear and similar equipment. Discharging can take place at up to 110 A, and if higher current is needed, two or more TORKEL 840 units or extra load units, TXL, can be linked together. Tests can be conducted at constant current, constant power, constant resistance or in accordance with a pre-selected load profile.

TORKEL 860 - MULTI is designed primarily for people who travel from place to place to maintain battery systems having different voltages. It features excellent discharging capacity plus a broad voltage range and outstanding portability – a unique combination.

TORKEL 860 is used for systems ranging from 12 to 480 V, and discharging can proceed at up to 110 A. If higher current is desired, two or more TORKEL 860 units or extra load units, TXL, can be linked together. Discharging can take place at constant current, constant power, constant resistance or in accordance with a pre-selected load profile.

## Application example

### IMPORTANT!


## Read the User's manual before using the instrument.

Testing can be carried out without disconnecting the battery from the equipment it serves. Via a DC clamp-on ammeter, TORKEL measures total battery current while regulating it at a constant level.


- 1. Connect TORKEL to battery.
- 2. Set the current and voltage alarm level
- **3.** Start discharging. TORKEL keeps the current constant at the preset level.
- 4. When the voltage drops to a level slightly above the final voltage, TORKEL issues an alarm.
- 5. If the voltage drops low enough so that there is risk of deepdischarging the battery, TORKEL shuts down the test. The total voltage curve and the readings taken at the end of the test are stored in TORKEL. Later, using the TORKEL Win program which runs on a PC under Windows®, you can transfer these readings to your computer for storage, printout or export. If your PC is connected to TORKEL during the test, TORKEL Win builds up a voltage curve on the screen in real time and displays the current, voltage and capacity readings. You can also control the test using TORKEL Win.


## Application examples with TORKEL/TXL systems

TORKEL and TXL can be combined into systems to match up for different battery capacities. Here are two examples, you can find more in the section Battery Testing Accessories.



TORKEL and the extra load TXL





Example of multiple TORKEL and TXL arrangement

Specifications TORKEL 840/860
Specifications are valid at nominal input voltage and an ambient temperature of +25°C, (77°F). Specifications are subject to change without notice.

without notice.		
Environment		
Application field	The instrument is intended for use in high-voltage substations and industrial environments.	
Temperature		
Operating	0°C to +40°C (32°F to +104°F)	
Storage & trans- port	-40°C to +70°C (-40°F to +158°F)	
Humidity	5% – 95% RH, non-condensing	
CE-marking		
Safety standards	IEC 61010-1:2001 Incl. national dev. for US and CA EN 61010-1:2001	
EMC standards	EN 61326: 1997+A1:1998+A2:2001	
General		
Mains voltage	100 – 240 V AC, 50/60 Hz	
Power consumption (max)	150 W	
Protection	Thermal cut-outs, automatic overload protection	
Dimensions		
Instrument	210 x 353 x 700 mm (8.3" x 13.9" x 27.6")	
Transport case	265 x 460 x 750 mm (10.4" x 18.1" x 29.5")	
Weight	21.5 kg (47.4 lbs) 38 kg (83.8 lbs) with accessories and transport case.	
Display	LCD	
Available languages	English, French, German, Spanish, Swedish	
Measurement section	on	
<b>Current measureme</b>	ent	
Display range	0.0 – 2999 A	
Basic inaccuracy	±(0.5% of reading +0.2 A)	
Resolution	0.1 A	
Internal current me	asurement	
Range	0 – 270 A	
Input for clamp-on	ammeter	
Range	0 – 1 V	
mV/A-ratio	Software settable, 0.3 to 19.9 mV/A	
Input impedance	>1 MΩ	
Voltage measureme		
Display range 0.0 – 6		
Basic inaccuracy Resolution	±(0.5% of reading +0.1 V)	
	0.1 V	
Display range 0.0 – 5		
Basic inaccuracy	±(0.5% of reading +1 V)	
Resolution	0.1 V	
Time measurement	0.40/ - 5 12 4 - 12 - 12	
Basic inaccuracy	±0.1% of reading ±1 digit	

Load so	ection			
Max. battery voltage		288 V DC (TORKEL 840) 480 V DC (TORKEL 860)		
Max. current		110 A		
Max. power		15 kW		
Load patterns		Constant current, constant power, constant resistance, current or power profile		
Curre	ent setting	0-110.0 A (2999.9 A) <sup>1)</sup>		
Powe	er setting	0-15.00 kW (299.99	9 kW) <sup>1)</sup>	
Resistance setting		0.1-2999.8 Ω		
Battery voltage range, TORKEL 840		4 ranges, selected automatically at start of test		
Battery voltage range, TORKEL 860		5 ranges, selected automatically at start of test		
		±(0.5% of reading		
	Battery voltage	Highest permis- sible current	Resistor ele-	
	vortage	Sible current	ment (Nominal values)	
Range 1	10 – 27.6 V	110 A		
Range 1 Range 2			values)	
	10 – 27.6 V	110 A	<b>values)</b> 0.165 Ω	
Range 2	10 – 27.6 V 10 – 55.2 V	110 A 110 A	<b>values)</b> 0.165 Ω 0.275 Ω	
Range 2 Range 3	10 – 27.6 V 10 – 55.2 V 10 – 144 V	110 A 110 A 110 A	<b>values)</b> 0.165 Ω 0.275 Ω 0.55 Ω	
Range 2 Range 3 Range 4 Range 5 2)	10 – 27.6 V 10 – 55.2 V 10 – 144 V 10 – 288 V 10 – 480 V value for a system with	110 A 110 A 110 A 55 A 55 A (max power	values) 0.165 Ω 0.275 Ω 0.55 Ω 3.3 Ω	
Range 2 Range 3 Range 4 Range 5 2) 1) Maximum 2) TORKEL 86	10 – 27.6 V 10 – 55.2 V 10 – 144 V 10 – 288 V 10 – 480 V value for a system with	110 A 110 A 110 A 55 A 55 A (max power 15 kW) more than one load unit	values) 0.165 Ω 0.275 Ω 0.55 Ω 3.3 Ω	
Range 2 Range 3 Range 4 Range 5 2) 1) Maximum 2) TORKEL 86	10 – 27.6 V 10 – 55.2 V 10 – 144 V 10 – 288 V 10 – 480 V value for a system with 50 maximal value.	110 A 110 A 110 A 55 A 55 A (max power 15 kW) more than one load unit	$values$ ) $0.165 \Omega$ $0.275 \Omega$ $0.55 \Omega$ $3.3 \Omega$ $3.3 \Omega$	
Range 2 Range 3 Range 4 Range 5 <sup>2)</sup> 1) Maximum 2) TORKEL 80 Inputs, EXTERNA CURRENT MEASURI START/ST	10 – 27.6 V 10 – 55.2 V 10 – 144 V 10 – 288 V 10 – 480 V value for a system with 50 maximal value.	110 A 110 A 110 A 110 A 55 A 55 A (max power 15 kW) more than one load unit  IES 1 V DC, 300 V DC t shunt should be con negative side of the Closing/opening cc Closing and then on will start/stop Torke	$values$ ) $0.165 \Omega$ $0.275 \Omega$ $0.55 \Omega$ $3.3 \Omega$ $3.3 \Omega$	

mpats, maxima values		
EXTERNAL CURRENT MEASUREMENT	1 V DC, 300 V DC to ground. Current shunt should be connected to the negative side of the battery	
START/STOP	Closing/opening contact Closing and then opening the contact will start/stop Torkel. It is not possible to keep the contacts in closed position.	
Delay until start	200 – 300 ms	
Stop delay	100 – 200 ms	
Battery	480 V DC, 500 V DC to ground	
VOLTAGE SENSE	480 V DC, 500 V DC to ground	
SERIAL	< 15 V	
ALARM	250 V DC 0.28 A 28 V DC 8 A 250 V AC 8 A	

Outputs, maximal values		
START/STOP	5 V, 6 mA	
TXL	Relay contact	
SERIAL	< 15 V	
ALARM	Relay contact	

Discharging capacity, examples 12 V battery (6 cells) 3)				
1.80 V/cell (10.8 V)	0 – 50.0 A	0 – 0.54 kW		
1.75 V/cell (10.5 V)	0 – 49.0 A	0 – 0.51 kW		
1.67 V/cell (10.0 V)	0 – 46.0 A	0 – 0.46 kW		
24 V battery (12 cell	(s) <sup>3)</sup>			
1.80 V/cell (21.6 V)	0 – 110 A	0 – 2.37 kW		
1.75 V/cell (21.0 V)	0 – 110 A	0 – 2.31 kW		
1.60 V/cell (19.2 V)	0 – 100 A	0 – 1.92 kW		
48 V battery (24 cel	ls) <sup>3)</sup>			
1.80 V/cell (43.2 V)	0 – 110 A	0 – 4.75 kW		
1.75 V/cell (42.0 V)	0 – 110 A	0 – 4.62 kW		
1.60 V/cell (38.4 V)	0 – 110 A	0 – 4.22 kW		
110 V battery (54 ce	lls) <sup>3)</sup>			
1.80 V/cell (97.2 V)	0 – 110 A	0 – 10.7 kW		
1.75 V/cell (94.5 V)	0 – 110 A	0 – 10.4 kW		
1.60 V/cell (86.4 V)	0 – 110 A	0 – 9.5 kW		
120 V battery (60 ce	ells) <sup>3)</sup>			
1.80 V/cell (108 V)	0 – 110 A	0 – 11.9 kW		
1.75 V/cell (105 V)	0 – 110 A	0 – 11.5 kW		
1.60 V/cell (96 V)	0 – 110 A	0 – 10.5 kW		
220 V battery (108 d	:ells) <sup>3)</sup>			
1.80 V/cell (194 V)	0 – 55 A	0 – 10.7 kW		
1.75 V/cell (189 V)	0 – 55 A	0 – 10.4 kW		
1.60 V/cell (173 V)	0 – 51.0 A	0 – 8.82 kW		
240 V battery (120 d	:ells) 3)			
1.80 V/cell (216 V)	0 – 55 A	0 – 11.9 kW		
1.75 V/cell (210 V)	0 – 55 A	0 – 11.5 kW		
1.60 V/cell (192 V)	0 – 55 A	0 – 10.5 kW		
UPS battery (180 ce	lls) 3) (TORKEL	860)		
1.70 V/cell (306 V)	0 – 38 A	0 – 15 kW		
1.60 V/cell (288 V)	0 – 38 A	0 – 15 kW		
UPS battery (204 ce	lls) 3) (TORKEL	860)		
1.80 V/cell (367 V)	0 – 34 A	0 – 15 kW		
1.60 V/cell (326 V)	0 – 34 A	0 – 15 kW		
3) 2.15 V per cell when test starts				



Cable set GA-00550

Ordering information	Art.No.
TORKEL 840	
Complete with:	
Cable set GA-00550	
Transport case GD-00054	BS-49094
TORKEL 860	
Complete with:	
Cable set GA-00550	
Transport case GD-00054	BS-49096
Optional accessories	
See section "Battery Testing Accessories"	

## Programma

## NOTICE OF COPYRIGHT & PROPRIETARY RIGHTS

© 2008, Programma Electric AB. All rights reserved.

The contents of this document are the property of Programma Electric AB. No part of this work may be reproduced or transmitted in any form or by any means, except as permitted in written license agreement with Programma Electric AB.

Programma Electric AB has made every reasonable attempt to ensure the completeness and accuracy of this document. However, the information contained in this document is subject to change without notice, and does not represent a commitment on the part of Programma Electric AB.

### TRADEMARK NOTICES

Megger® and Programma® are trademarks registered in the U.S. and other countries.

All other brand and product names mentioned in this document are trademarks or registered trademarks of their respective companies. Programma Electric AB is certified according to ISO 9001 and 14001.



Programma Electric AB Eldarvägen 4 Box 2970 SE-187 29 TÄBY Sweden

T +46 8 510 195 00 F +46 8 510 195 95 info@programma.se www.programma.se