New Flagship



Electrical Safety Multi-analyzer TOS9300 Series

All-in-one safety tester model (TOS9303LC)

Insulation diagnosis available with partial discharge model (TOS9301PD)

New amplifier type allows for 40 A AC/DC ground bond testing (Ground bond tester models)

Electrical breakdown inspection setting available

AC5 kV/100 mA, DC7.2 kV/100 W Hipot test

Touch current/protective conductor current/leakage current test (TOS9303LC)

LAN/USB/RS232C standard digital interface

Easy to read LCD display for real time monitoring during tests

All measurement values and standard outlines displayed in each test

High voltage scanner capable of output distribution both standalone and when connected with existing withstanding voltage/insulation resistance testing equipment models [TOS5300 series, etc.] (TOS9320)

THE ALL-ROUN

Hipot, Insulation Resistance, Ground Bond, Leakage or Partial Discharge, this analyzer covers it all!

TOS9300 Series Lineup

T0S9300

AC Hipot Tester with Insulation Resistance Test

ACW 5 kV/100 mA(500 VA)

0.001 MΩ to 100.0 GΩ (DC-25 V to -1000 V)









- D 430(16.93")(440(17.32"))W×132(5.2")(155(6.10"))H× 370(14.57")(410(16.14"))Dmm(inch)
- W Approx.17 kg(37.5 lbs)

T0S9302

AC Hipot Tester with Ground Bond Test





- D 430(16.93")(440(17.32"))W×132(5.2")(155(6.10"))H× 500(19.69")(540(21.26"))Dmm(inch)
- W Approx.20 kg(44.1 lbs)

T0S9301

AC/DC Hipot Tester with Insulation Resistance Test

ACW 5 kV/100 mA(500 VA)

DCW 5 kV/20 mA, 7.2 kV/13.9 mA(100 W)
IR 0.001 MΩ to 100.0 GΩ (DC-25 V to -1000 V/DC+50 V to +7200 V)







- D 430(16.93")(440(17.32"))W×132(5.2")(155(6.10"))H× 370(14.57")(410(16.14"))Dmm(inch)
- W Approx.18 kg(39.7 lbs)

T0S9303

AC/DC Hipot Tester with Insulation Resistance and Ground Bond Test

ACW 5 kV/100 mA(500 VA)

DCW 5 kV/20 mA, 7.2 kV/13.9 mA(100 W)

IR 0.001 MΩ to 100.0 GΩ (DC-25 V to -1000 V/DC+50 V to +7200 V) EC 0.001 Ω to 0.600 Ω (3.0 A to 42.0 A)







- D 430(16.93")(440(17.32"))W×132(5.2")(155(6.10"))H× 500(19.69")(540(21.26"))Dmm(inch)
- W Approx.21 kg(46.3 lbs)

T0S9301PD

AC/DC Hipot Tester with Insulation Resistance and Partial Discharge Test

ACW 5 kV/100 mA(500 VA)

CW 5 kV/20 mA, 7.2 kV/13.9 mA(100 W)

IR 0.001 MΩ to 100.0 GΩ (DC-25 V to -1000 V/DC+50 V to +7200 V)

PD 5 kV/50 mA(250 VA)





LAN USB RS232C (Timer)

- D 430(16.93")(440(17.32"))W×132(5.2")(150(5.9"))H× 525(20.67")(565(22.24"))Dmm(inch)
- W Approx.22 kg(48.5 lbs)

T0S9303LC

AC/DC Hipot Tester with Insulation Resistance, Ground Bond, and Leakage Current Test

ACW 5 kV/100 mA(500 VA)

DCW 5 kV/20 mA, 7.2k V/13.9 mA(100 W)

IR 0.001 MΩ to 100.0 GΩ (DC-25 V to -1000 V/DC+50 V to +7200 V)

EC 0.001 Ω to 0.600 Ω (3.0 A to 42.0 A)

LC 1 µA to 100 mA(rms)

Rise Time Fall Time



- D 430(16.93")(440(17.32"))W×132(5.2")(155(6.10"))H× 500(19.69")(550(21.65"))Dmm(inch)
- W Approx.22 kg(48.5 lbs)

Test items


Model	AC Withstanding Voltage (AC Hipot)	DC Withstanding Voltage (DC Hipot)	Insulation Resistance	Earth Continuity (Ground Bond)	Leakage Current	Partial Discharge
T0S9300	•		•			
T0S9301	•	•	•			
T0S9301PD	•	•	•			•
T0S9302	•			•		
T0S9303	•	•	•	•		
T0S9303LC	•	•	•	•	•	
T0S9320	4 chann	nel high voltage sc	anner with conta	ct check function	can be used star	ndalone.



Electrical Safety Multi-analyzer TOS9300 Series

The TOS9300 series is a high-performance electrical safety analyzer that complies with a wide range of universal standards. Hipot, Insulation Resistance, Ground Bond, Leakage Current (touch current and protective conductor current) and partial discharge can all be tested. A total of 6 models are available for standard compliance tests for a wide variety of applications including R&D, quality assurance manufacturing lines and laboratory tests.

- All-in-one safety tester model (TOS9303LC)
- Insulation diagnosis available with partial discharge model (TOS9301PD)
- New amplifier type allows for 40A AC/DC ground bond testing (Ground bond tester models)
- Electrical breakdown inspection setting available
- AC5 kV/100 mA, DC7.2 kV/100 W Hipot test
- Touch current/protective conductor current/leakage current testing (TOS9303LC)
- LAN/USB/RS232C standard digital interface
- Easy-to-read LCD display for real-time monitoring during tests.
 All measurement values and standards outlines are displayed during each test
- High voltage scanner capable of output distribution both standalone and when connected with existing withstanding voltage/insulation resistance testing equipment models [TOS5300 series, etc.] (TOS9320)



The Electrical Appliance & Material Safety Low (Japan), UL (U.S.A.), CSA (Canada), VDE (Germany) and BS (U.K) are some major examples of safety standards in use throughout the world that require the performing of hipot testing. For this reason, it is necessary to confirm for what portion of what standard testing is to be performed when purchasing a hipot tester. Although the 500 VA capacity hipot testers available from KIKUSUI can basically be applied to tests specified in all safety standards, we recommend that you consult with us prior to purchase in order to select the model that best matches your specific application.


For the withstanding test and the insulation resistance test of the EUT (equipment under test) with turned on electricity.

Our hipot testers and insulation resistance testers are designed to test the EUT(equipment under test) with the electricity turned off. In case the test requires the EUT(equipment under test) to be turned off, please contact our distributor or agent.

Features

Color LCD Screen for Improved Visibility!

A brand-new, 7-inch LCD display allows for easy access to your custom settings, standard outlines and blueprints for easy operation. (See Exterior Design P10/Display P11)



User-Friendly, 10-Key Configuration

The TOS9300 series has included a user-friendly keypad in addition to the basic rotary knob for easy configuration setting. The front panel USB interface also allows for direct control via keyboard*.





*106/109 Japanese keyboards and 101/104 English keyboard compliant

Easy Firmware Updates via USB

System firmware can easily be updated via USB memory with updated files directly accessible from our website. (https://www.kikusui.co.jp/en/download/)





LAN/USB/RS232C Standard Digital Interface

LXI compatible LAN, USB 2.0, USB-TMC compatible USB, and RS232C as standard digital interface.



* Connecting with a smartphone, tablet, etc. requires a Wi-Fi environment (wireless LAN router etc.).



▲Rear panel, Interface(All models)

Use a browser from a PC, smartphone, or tablet to access the web server built into the TOS9300 series for convenient control and monitoring.

[Recommended browser]

- Requires for the Internet Explorer version 9.0 or later
- Requires for the firefox 8.0 or later
 Requires for the safari / mobile Safari 5.1 or later
- Requires for the Chrome 15.0 or later
 Requires for the Opera 11.0 or later

I/V Monitor Terminal (Analog Monitor)

Signal outputs on the rear panel I/V terminal allow the user to monitor current/voltage waveforms during hipot tests with only an oscilloscope. Current sensors and high-voltage probes are not required.



Can connect with an oscilloscopusing a BNC cable.

*There is no BNC cable option available. Users need to acquire a BNC cable themselves.

STATUS OUT Connector

Signals from the rear panel STATUS connector automatically activate the optional warning light (PL02-TOS) during high voltage output or unsafe test conditions.






SIGNAL I/O Connector

The rear panel also has a SIGNAL I/O that can start/stop operation as well as output signals.

TOS9300 example (The SIGNAL I/O connector is the same on all models.)



	1	()	/ >
Pin no.	IN/OUT	Signal name	Description
1	IN	INTERLOCK+	Activate/release interlock.
2	_	COM	Circuit common (chassis potential) shared by input and output.
3	IN	PM0	
4	IN	PM1	
5	IN	PM2	
6	IN	PM3	Calcat active managing and quita test assessment managing
7	IN	PM4	Select setup memories and auto test program memories.
8	IN	PM5	
9	IN	PM6	
10	IN	PM7	
11	IN	STB	Recall setup memories and programs selected with the PM0 to PM7 signals.
12	_	Reserved	
13	_	Reserved	Not used.
14	_	Reserved	
15	IN	START	Start a test.
16	IN	STOP	Stop a test.
17	IN	ENABLE	Enable the START signal.
18	_	СОМ	I/O circuit common (chassis potential).
19	IN	INTERLOCK-	Activate/release interlock.
20	_	СОМ	I/O circuit common (chassis potential).
21	_	+24V	+24 V internal power supply output terminal. Maximum output current 100 mA.
22	OUT	H.V ON/LINE ON	Set to on in any of the following conditions. Testing. Auto testing. Voltage remaining across the output terminals. Power being supplied to the EUT from the TOS9303LC through AC LINE OUT.
23	OUT	RISE	Set to on when the voltage is rising.
24	OUT	TEST	Set to on during test time.
25	OUT	PASS	Set to on for the duration of time specified by Pass Hold when a PASS judgment is made.
26	OUT	U FAIL	Set to on continuously when a U-FAIL judgment is made. Or set to on continuously along with the L FAIL signal when CONTACT FAIL judgment is made when a scanner is connected.
27	OUT	L FAIL	Set to on continuously when an L-FAIL judgment is made. Or set to on continuously along with the U FAIL signal when CONTACT FAIL judgment is made when a scanner is connected.
28	_	Reserved	Not used.
29	OUT	READY	Set to on when the product is ready to start a test.
30	OUT	PROTECTION	Set to on when a protection function is activated.
31	OUT	STEP END	Set to on when each step ends during an auto test.
32	OUT	CYCLE END	Set to on when the last step ends during an auto test.
33	OUT	ACW	Set to on when the test mode is set to AC withstanding voltage test.
34	OUT	DCW	Set to on when the test mode is set to DC withstanding voltage test.
35	OUT	IR	Set to on when the test mode is set to insulation resistance test.
36	OUT	EC	Set to on when the test mode is set to earth continuity test.
37	OUT	LC	Set to on when the test mode is set to touch current test or

protective conductor test.



Universal Input Support

Global Support


TOS9300 Series supports universal input for varying input voltages around the world.

 Programmable Output Frequency Stable output frequency not dependent on input power source. Testing voltage is supplied at a stable 50/60Hz frequency.



AC Hipot Testing with Stable Output [Input Voltage Variation: ±0.3%]

Conventional hipot testers utilize a slide transformer to output AC line voltage. This design is susceptible to input voltage fluctuation, with outside electrical influence affecting the test results. This can result in distorted voltage being applied to the EUT which can cause product malfunctions down the line due to component malfunction. The TOS9300 series utilizes a highly efficient PWM amplifier capable of stable high-voltage output that is unaffected by changes in the AC power line. The TOS9300 series allows for safe, stable, and highly reliable tests regardless of AC power line instability.



High Precision/High Resolution/High Speed

The TOS9300 is equipped with a highly accurate, high resolution RMS measurement circuit with a voltmeter of \pm (1.2% of reading +5 V)/minimum resolution 0.1 V and an ammeter of \pm (1% of reading +2 μ A)/ minimum resolution 1 μ A. The series also supports an auto range function, ensuring similar accuracy in both the upper and lower limit measurements that can accurately detect connection problems in the test lead. This, combined with a measurement speed of 0.1s, allows for reliable testing with high accuracy and resolution.

Supports testing for partial discharge (TOS9301PD)

By observing minute partial discharges, it is possible to detect deterioration inside the insulation and "potential defects" that can affect the life of the insulation, which cannot be detected by the withstand voltage test. (See Application P9 and Specification P18)



Automatic Testing Feature

Tests can be combined and configured to execute automatically over long periods of time. Automatic tests are composed of programs and steps, which can be configured to initiate one after another.

Program schematic




	Maximum number	Maximum number	Executed under	Changing the
	of programs	of steps *1	external control	program name
Program memory (except LC tests)	100	100	-	1
Program memory (LC tests only) *2	100	100	-	✓
	Maximum number	Maximum number	Executed under	Changing the
	of programs	of steps *1	external control	program name
External control program memory (except LC tests)	25	100	✓	-
External control Program memory (LC tests only) *2	24	100	1	-

^{*1} Per program *2 TOS9303LC only

Contact/Protective Conductor/ Patient Leakage Current Test (TOS9303LC)

The TOS9300 series can conduct leakage current (patient current) tests for highly sensitive medical devices. Measurement networks can be easily configured via the front panel. (See Applications P8, Specifications P21)



All Electrical Safety Standard Tests in One Device! (TOS9303LC)

The TOS9303LC is the "all-rounder" model that supports AC/DC withstanding voltage, insulation resistance, AC/DC earth continuity and leakage currents tests in a single device. It can also be used for contact current, protective conductor current and patient leakage current tests.

ACW 5 kV/100 mA(500 VA) DCW 5 kV/20 mA, 7.2 kV/13.9 mA(100 W) IR 0.001 MΩ to 100.0 GΩ (DC-25 V to -1000 V/DC+50 V to +7200 V) EC 0.001 Ω to 0.600 Ω (3.0 A to 42.0 A) LC 1 μA to 100 mA(rms)



Features

Programmable Detection Response Speed

Conventional withstanding voltage testers are generally used to only detect insulation breakdown, and cannot make judgements on instantaneous discharge currents like partial discharge. However, the TOS9300 series is equipped with 5 levels of response speed settings to accurately detect low levels of insulation breakdown. Small discharges not visible to conventional withstanding voltage testers are easily detected with the TOS9300 series.

Value		Description
LPF	Slow	Mean value response type current detector. This is similar to the current detection response of Kikusui's general-purpose AC withstanding voltage testers. This setting is suitable for detecting dielectric breakdown defined in safety standards and for general hipot tests for general electronic devices and components. This setting is not recommended for detecting corona discharge, which is not considered dielectric breakdown by typical safety standards.
	Medium	Mean value response type is faster than the SLOW setting. Upper
	Fast	limit judgement detection is much faster, suitable for withstanding voltage tests on compact electronic components and other EUTs prone to dielectric breakdown. Instantaneous discharges such as corona discharges with high frequencies are detected which may not be suitable for simple withstanding voltage tests.
HPF	Slow	Extremely small discharges such as corona discharges are detected but
пРГ	Fast	with low reproductibility.



7.2 kV/100 W DC Hipot Test

Capable of performing DC Hipot tests up to 7.2 kV utilizing a stable DC/DC converter with low-ripple and load variation of 1% and below.



Positive Electrode/Negative Electrode Insulation Resistance Testing

Testing voltage from -25 V to -1000 V, +50 V to +7200 V, with a setting resolution is 1 V. Insulation resistance can be tested up to 99.99 G Ω . This makes for easy IEC61730-2 standard PV (solar battery) module insulation resistance testing. (See Application P9)



Electric Discharge Function

A discharge feature enables discharge of electrical energy from the DUT after DC hipot and insulation resistance tests have been completed. The setting range for discharge time is between 0.0s - 100.0s.


AC/DC Earth Continuity Testing up to 40 A

Cutting edge amp technology allows for a wide range of applications, including general AC earth conduction testing and EV/PHV system DC earth continuity testing. This also allows for strict adherence to automotive DC standard requirements, which are expected to increase in the near future.



EARTH FAULT Protection

Mistakenly changing the grounding (GND) setting to "guard" (floating) can result in grounding the test subject which can result in unwanted leakage current emissions from the high voltage output site into the grounding site, resulting in electric shock to the operator. The EARTH FAULT protection function blocks output and terminates the test; eliminating any risk of electric shock and maximizing safety for the operator.



Offset Cancel


The Offset Cancel feature allows the user to eliminate electrical current found in the insulation resistance and stray capacitance among the output cables (only resistance for DC testing). This feature is available in all testing modes for AC withstanding voltage, DC withstanding voltage, insulation resistance, earth continuity and electrical current leakage tests.



Rise Time/Fall Time Control Function


The rise time control function prevents unnecessary stress from being applied to the EUT.

Rise Time control function



The rise time control feature allows you to gradually increase voltage to a set value while AC/DC hipot tests are conducted. Voltage rise times can be set from 0.1s to 200.0s at a resolution of 0.1s.


Fall time control function



The fall time control feature allows you to gradually decrease the test voltage after a successful AC/DC hipot test. The voltage fall time can be set from 0s to 200s at a resolution of 0.1s. (OFF is also selectable).

Basic Memory Function

In addition to automatic testing memory functions, up to 51 basic setting conditions and testing modes can be selected and saved to the main unit or USB memory. Easy testing with no hassle!



Calibration Deadline Notification

A real-time clock IC has been equipped to ensure that the instrument is traceable via regular calibration. The device will automatically generate warning notifications when the calibration deadline has exceeded.

Multi-Channel Testing System (Optional)

The TOS9320 high voltage scanner allows for rapid distribution of testing voltage from the main unit to multiple testing points for withstanding voltage and insulation resistance testing. Channels can be controlled via an external device through the rear panel CONTROLLER INTERFACE connector. The scanner can also be used standalone or with an external control device for other Kikusui withstanding voltage and insulation resistance testing instruments. Hipot tests for electronic devices with multiple testing points have never been easier. (See Application P9)

[High-voltage scanner TOS9320]






▲Rear panel

- Output can be expanded to four channels with one high-voltage scanner. The electric potential of each channel can be arbitrarily set to high, low, or open, and can be tested at any of these four points.
- Up to four high voltage scanners (total 16 channels) can be connected to each unit.
- Output of each channel and contact with testing points can be easily monitored.






Application

Leakage Current Test

Compatible with medical device leakage current testing (patient current)! (TOS9303LC only)




Measurement circuit network (network I IEC60601-1)

Electrical safety standard testing for automotive components

▲TOS9303LC

Compatible with both AC and DC, the TOS9303LC complies with a wide variety of safety tests for EV batteries, automotive charging devices and charging connectors. This "all-in-one" safety analyzer can meet the needs of nearly all automotive electrical safety standards.






PV (solar battery) module withstanding voltage/insulation resistance testing

Withstanding voltage tests such as IEC61730-2 and JIS C 8992-2 require testing voltage to be drastically increased (4 times the maximum system voltage + 2000 V) and maintained for 1 minute.

[Voltage 1000 V adaptation grade A example]


1000 V × 4-fold + 2000 V = **Test voltage** : **6000 V**



Partial discharge

[EUT (example): small motors, transformers, insulating materials, etc.]


The partial discharge test detects the state before dielectric breakdown, so it can detect potential defects and manufacturing variations that cannot be detected by the conventional withstand voltage test.



Multi-channel withstanding voltage/insulation resistance testing

Multiple testing points can be simultaneously tested to cut costs and save time!

The TOS9320 high voltage scanner allows for multi channel expansion for the TOS9300 series as well as previous models.



^{*1} Independent control of the scanner is required using EXTERNAL I / O.

^{*} Mount on a rack when using two or more scanners


Exterior Design

Front panel

●TOS9303LC

DANGER LED

Lights red when the power is turned on, when a test is in progress, when a high voltage is being output, or when there is residual voltage at the output terminals. On the TOS9303LC, the LED also lights red when supply voltage is being supplied to the EUT.






AC INPUT inlet

100 V to 120 V/ 200 V to 240 V

I terminal

Signal output terminal for monitoring current



●TOS9301PD

Ipd terminal
Signal output terminal for
monitoring the discharge
waveforms of partial discharge.

Signal output terminal for

Opd terminal


monitoring the electric charge waveforms of partial discharge.






Display (Each menu screen)

●TOS9303LC screen example





▲Function Menu

Displays summary of settings for each test. Switch test modes.



Configure and execute auto tests.



▲Memory Menu
Use memory function.



Display and change system settings.

Unless specified otherwise, the specifications are for the following settings and conditions.

- . The product is warmed up for at least 30 minutes.
- The product is warmed up for at least 30 minutes.
 TYP: These are typical values that are representative of situations where the product operates in an environment with an ambient temperature of 23 °C. These values do not guarantee the performance of this product.
 setting: Indicates a setting. range: Indicates the rated value of each range. reading: Indicates a readout value.
 The various tests are abbreviated as follows: ACW: AC withstanding voltage, DCW: DC withstanding voltage, IR: insulation resistance, EC: earth continuity, LC: leakage current, TC: touch current, PCC: protective conductor current, Patient: patient leakage current, Meter: meter mode

■ Withstanding Voltage Test

IAC Output function

Item			TOS9300	TOS9301	TOS9301PD	TOS9302	TOS9303	TOS9303LC		
			0.050 kV to 5.000 kV	/						
	Output range	Resolution	1 V							
		Setting accuracy	±(1.2 % of setting +	0.02 kV) (at no load)						
	Max. rated load *1		500 VA(5 kV / 100 m	nA)						
	Max. rated current		100 mA (when the o	utput voltage is 0.2 k	V or higher)					
	Transformer rating		500 VA							
C output	Output voltage		Sine	Sine						
section	waveform *2	Distortion	2 % or less. (when the output voltage is 0.5 kV or higher and no load or a pure resistive load is connected)							
	Crest factor		√2 ± 3 % (800 V or more)							
	Fraguanay		50 Hz / 60 Hz							
	Frequency	Accuracy	±0.1 %							
	Voltage regulation		±3 % or less (when changing from maximum rated load to no load)							
	Short-circuit currer	nt	200 mA or more (output voltage 0.5 kV or higher)							
	Output method		PWM switching							
Start voltage			The voltage at the s	tart of the test can be	set.					
		Setting range	1 % to 99 % of the te	est voltage						
		Resolution	1 %				•			
output voltag	e monitor function		If the output voltage	If the output voltage exceeds ±(10 % of setting + 0.05 kV), the output is turned off, and the protection function is activated.						

[DC Output function]

Item			TOS9301	TOS9301PD	TOS9303	TOS9303LC				
	Output voltage ra	nge	0.050 kV to 7.200 kV							
		Resolution	1 V	1 V						
		Setting accuracy	±(1.2 % of setting + 0.02 kV)							
	Max. rated load *	1	100 W (5 kV/20 mA, 7.2 kV/13.	9 mA)						
DC output section	Max. rated curren	it	20 mA							
	Dinnle	7.2 kV no load	20 Vp-p (TYP)							
	Ripple	Max. rated load	50 Vp-p (TYP)							
	Voltage regulation	n	1 % or less (when changing fro	1 % or less (when changing from maximum rated load to no load)						
	Short-circuit curre	ent	100 mA (TYP) (200 mA peak)	100 mA (TYP) (200 mA peak)						
	Discharge function	n	Forced discharge after test completion (discharge resistance: 125 kΩ)							
Start voltage			The voltage at the start of the t	est can be set.						
		Setting range	1 % to 99 % of the test voltage	1 % to 99 % of the test voltage						
		Resolution	1 %							
Output voltage monitor function			If the output voltage exceeds ±(10 % of setting + 0.05 kV), the output is turned off, and the protection function is activated.							

^{*1} When tests are performed consecutively, output time limit and rest time may become necessary depending on the upper limit setting

[Measurement function]

Item		TOS9300	TOS9301	TOS9301PD	TOS9302	TOS9303	TOS9303LC					
	Measurement range	0.00 kV to 7.50 kV A	0.00 kV to 7.50 kV AC/DC									
	Resolution	0.1 V	0.1 V									
	Accuracy	±(1.2 % of reading +	5 V)									
Voltmeter		Can be switched be	tween true rms and r	nean-value response	rms conversion.							
	Response	Peak-value respons	e in a separate syste	m								
		(the peak-value response is for measuring the dielectric breakdown voltage while rising)										
	Hold function	The voltage measur	The voltage measurement after a test is finished is held while the pass/fail judgment is displayed.									
	Measurement range	AC: 0.00 mA to 110	AC: 0.00 mA to 110 mA, DC: 0.00 mA to 22 mA (Current including the active component and reactive component)									
	Accuracy	±(1 % of reading + 2	±(1 % of reading + 2 μA) (active component)									
	Response	Can be switched be	Can be switched between true rms and mean-value response rms conversion.									
Ammeter	Hold function	The current measure	The current measurement after a test is finished is held while the pass judgment is displayed.									
*1 *2	Offset cancel function	Cancels up to 10 m/	Cancels up to 10 mA of the current flowing through the insulation resistance and stray capacitance components across									
	Offset caricer function	output cables and th	output cables and the like (resistance component only for DC tests). OFF function available.									
	Calibration	Active component: 0	Calibrated with the rr	ns of a sine wave usin	ng a pure resistive lo	ad.						
	Calibration	Reactive componen	Reactive component: Not calibrated.									

^{*1} During AC voltage tests, current also flows in the stray capacitance of items such as the test leads and tools. For details on stray capacitance, see "Stray Capacitance of AC Withstanding Voltage Tests"

^{*2} If an AC voltage is applied to a capacitive load, the output voltage may rise higher than at no load depending on the load capacitance. Further, waveform distortions may occur if an EUT whose capacitance is dependent on voltage (for example, an EUT that consists of ceramic capacitors) is connected as the load. However, if the test voltage is 1.5 kV, the effect of a capacitance of 1 000 pF or less can be ignored. Because the product's high-voltage power supply uses the PWM switching method, if the test voltage is 500 V or less, the switching and spike noise proportions are large. The lower the test voltage, the greater the waveform is distorted.

^{*2} When the temperature and humidity are high, erroneous current from the product's internal and external high-voltage wiring sections to ground increases. When the humidity exceeds 70 %, an erroneous current of about 50 μA may be generated.



[Judgment function]

Item			TOS9300	TOS9301	TOS9301PD	TOS9302	TOS9303	TOS9303LC		
Current iud	Igment operation				s made. Buzzer volum					
	J			fail separately. In an auto test, the buzzer is valid only for the judgment that takes place at the end of the program.						
		Judgment method		UPPER FAIL results when a current greater than or equal to the Upper limit is detected. For DCW, judgment is not made during the judgment delay (Judge Delay).						
			., .		the judgment delay (Ju	idge Delay).				
	UPPER FAIL	Display	"Upper-FAIL" is disp	layed.						
		Buzzer	On	-						
		SIGNAL I/O			tinuously until a STOF					
		Judgment method			s than or equal to the se time or Voltage fall					
	LOWER FAIL	Display	"Lower-FAIL" is disp	layed.						
		Buzzer	On							
		SIGNAL I/O	The Lower-FAIL sig	nal is generated con	tinuously until a STOF	signal is received.				
		Judgment method	PASS judgment is r	nade if Upper-FAIL o	r Lower-FAIL has not	occurred when the te	est time elapses.			
		Display	"PASS" is displayed							
	PASS	Buzzer	On (fixed to 50 ms)							
		SIGNAL I/O			ngth of time specified			d.		
Voltage rise	e rate judgment operati	ion	set to on and the ou	tput voltage is 200 V	tage rise time. This is or more. The output it ass and fail separatel	s shut off when a jud				
		Judgment method	When the voltage ri	se rate (dV/dt) is less	s than approx. 1 V/s.					
		Display	" Upper-FAIL(dv/dt)	' is displayed.						
	dV/dt FAIL	Buzzer	ON	· · ·	,			,		
		SIGNAL I/O	The U FAIL signal is	generated continuo	ously until a STOP sign	nal is received.				
Upper limit	setting range	,	AC: 0.01 mA to 110	00 mA, DC: 0.01 mA	A to 21.00 mA					
Lower limit	setting range		AC: 0.00 mA to 109	.99 mA, DC: 0.00 m/	A to 20.99 mA, OFF. S	etting 0.00 is equiva	lent to OFF.			
Judgment accuracy *1 *2			±(1 % of setting + 5 µA)							
Current det	tection method		Compares to the reference value using the following method. Calculate true rms values, convert mean-value responses to rms values							
Response	speed (filter) switching			Switches the current detection response speed (sensitivity) used in UPPER FAIL judgment between five levels in ACW and						

^{*1} During AC voltage tests, current also flows in the stray capacitance of items such as the test leads and tools. For details on stray capacitance, see "Stray Capacitance of AC Withstanding Voltage Tests"

[Timer function]

Item	TOS9300	TOS9301	TOS9301PD	TOS9302	TOS9303	TOS9303LC		
Voltage rise time settings range	0.1 s to 200.0 s).1 s to 200.0 s						
Voltage fall time setting time *1	0.1 s to 200.0 s, OFF	0.1 s to 200.0 s, OFF						
Test time setting range	0.1 s to 1000.0 s, OF	F						
Judgment delay (Judge Delay) setting range *2	0.1 s to 100.0 s, AUTO *3 (DCW only)							
Accuracy	±(100 ppm of setting	(100 ppm of setting + 20 ms) (excluding the fall time)						

^{*1} This setting is used only when a PASS judgment occurs in ACW and DCW tests. During a DCW test, the voltage may not drop all the way within the set time because of the electrostatic capacity inside the product and the EUT.

[Other specifications]

F									
Item	TOS9300	TOS9301	TOS9301PD	TOS9302	TOS9303	TOS9303LC			
Analog monitor *1		Outputs a voltage si	gnal according to the	current waveform or	voltage waveform				
	I	Current waveform: S	Scale 50 mA/1 V						
	V	Voltage waveform: S	Scale 1 kV/1 V						
Grounding mode (GND)		Can be switched be	Can be switched between Low and Guard.						
	Low	GND is connected to	GND is connected to the low terminal. Measures the current flowing across the low terminal and chassis (normal						
	LOW	applications).	applications).						
Guard *2		GND is connected to	GND is connected to Guard. Measures only the current flowing through the low terminal (cur-rent flowing through the						
	Guard 2	chassis is not meas	chassis is not measured) (high sensitivity, high accuracy measure-ment applications).						

^{*1} Monitor signal output is isolated from the chassis (earth). If you connect an oscilloscope or an external device whose BNC shield is grounded, be sure to set the grounding mode (GND) to Guard. The value is not calibrated.

^{*2} When the temperature and humidity are high, erroneous current from the product's internal and external high-voltage wiring sections to ground increases. When the humidity exceeds 70 %, an erroneous current of about 50 µA may be generated.

^{*2} Less than the sum of the rise time and fall time.

^{*3} If Delay Auto is set to on, LOWER judgment is not made until the charge time ends.

^{*2} If there is a possibility that the EUT or tools and the like will be grounded or if you are uncertain, do not set GND to Guard. Doing so is extremely dangerous because the ammeter will be shorted and will not be able to measure current. For normal applications, set GND to Low.

■ Insulation Resistance Test

[Output function]

tem			TOS9300	TOS9301	TOS9301PD	TOS9303	TOS9303LC				
	0		-25 V to -1000 V	-25 V to -1000 V							
	Output voltage	Resolution	1 V								
Negative polarity	range	Setting accuracy	±(1.2 % of setting + 2 V)								
	Max. rated load		1 W (-1000 V/1 mA)								
	Dinale	1 kV no load	2 Vp-p or less								
	Ripple	Max. rated load	10 Vp-p or less								
	Short-circuit curre	ent	12 mA or less	12 mA or less							
	0	Outratually and		+50 V to +7200 V							
	Output voltage range	Resolution		1 V							
ositive	range	Setting accuracy		±(1.2 % of setting + 0.02 kV)							
ositive olarity *1	Max. rated load		_	- 7.2 W (7200 V/1 mA)							
olarity i	Ripple	1 kV no load		20 Vp-p or less							
	Кірріе	Max. rated load		50 Vp-p or less							
	Short-circuit curre	ent		100 mA (TYP) (200 mA	peak)						
Max. rated current		1 mA	1 mA								
Voltage regulation		1 % or less (when char	1 % or less (when changing from maximum rated load to no load)								
Discharge function		Forced discharge after	Forced discharge after test completion (discharge resistance: 20 kΩ)								
utput voltage	monitor function		If the output voltage ex	If the output voltage exceeds ±(10 % of setting + 50 V), the output is turned off, and the protection function is activated.							

^{*1} TOS9300 are not supported.

[Measurement function]

Item			TOS9300	TOS9301	TOS9301PD	TOS9303	TOS9303LC
	Measurement rai	nge	Negative polarity: 0 Vdc to -12	00 Vdc, positive	polarity: 0 Vdc to 7500 Vdc		
Voltmeter	Resolution		0.1 V				
	Accuracy		Negative polarity: ±(1 % of rea	ding + 1 V), Posi	tive polarity: ±(1.2 % of readi	ng + 5 V)	
	Measurement rai	nge	$0.001~\text{M}\Omega$ to $100.0~\text{G}\Omega$ (in the	range of maximu	m rated current of 1 mA to 5	nA)	
			500.000 MΩ ≤ R < 1.000 GΩ:	±(15 % of r	eading + 0.5 MΩ)		
		5 nA ≤ i ≤ 50 nA *3	1.000 GΩ ≤ R < 10.000 GΩ:	±(15 % of r	eading + 5 MΩ)		
			10.000 GΩ ≤ R ≤ 100.000 GΩ:	±(20 % of r	eading + 200 MΩ)		
			200.000 MΩ ≤ R < 1.000 GΩ:	±(10 % of r	eading + 0.5 MΩ)		
		F0 nA < i < 100 nA *0	1.000 GΩ ≤ R < 10.000 GΩ:	±(10 % of r	eading + 5 MΩ)		
		50 nA < i ≤ 100 nA *3	10.000 GΩ ≤ R < 50.000 GΩ:	±(10 % of r	eading + 50 MΩ)		
	Accuracy *1 *2		50.000 GΩ ≤ R ≤ 100.000 GΩ:	±(20 % of r	eading + 200 MΩ)		
	(when GND is		100.000 MΩ ≤ R < 1.000 GΩ:	±(7 % of re	ading + 0.5 MΩ)		
	set to Guard)	100 nA < i ≤ 200 nA *4	1.000 GΩ ≤ R < 2.000 GΩ:	±(7 % of re	ading + 5 MΩ)		
	(i: measured	100 HA < 1 \ 200 HA 4	2.000 GΩ ≤ R < 10.000 GΩ:	±(7 % of re	ading + 10 MΩ)		
	current)(R:		10.000 GΩ ≤ R < 50.000 GΩ:	±(7 % of re	ading + 100 MΩ)		
	measurement		10.000 MΩ≤ R < 100.000 MΩ:	±(5 % of re	ading + 0.05 MΩ)		
	resistance)	200 = 4 < i < 1 4 *4	100.000 MΩ ≤ R < 1.000 GΩ:	±(5 % of re	ading + 0.5 MΩ)		
		200 nA < i ≤ 1 μA *4	1.000 GΩ ≤ R < 10.000 GΩ:	±(5 % of re	ading + 5 MΩ)		
			10.000 GΩ ≤ R < 25.000 GΩ:	±(5 % of re	ading + 50 MΩ)		
		1 μA < i ≤ 1 mA *4	0.001 MΩ ≤ R < 10.000 MΩ:	±(2 % of re	ading + 0.003 MΩ)		
			10.000 MΩ ≤ R < 100.000 MΩ:	±(2 % of re	ading + 0.03 MΩ)		
			100.000 MΩ ≤ R < 1.000 GΩ:	±(2 % of re	ading + 0.3 MΩ)		
Desistence			1.000 GΩ ≤ R < 5.000 GΩ:	±(2 % of re	ading + 3 MΩ)		
Resistance meter		5 nA ≤ i ≤ 50 nA *3	500.000 MΩ≤ R < 1.000 GΩ:	±(25 % of r	eading + 0.5 MΩ)		
meter			1.000 GΩ≤ R < 10.000 GΩ:	±(25 % of r	eading + 5 MΩ)		
			10.000 GΩ≤ R ≤ 100.000 GΩ:	±(30 % of r	eading + 200 MΩ)		
		50 nA < i ≤ 100 nA *3	200.000 MΩ≤ R < 1.000 GΩ:	±(20 % of r	eading + 0.5 MΩ)		
			1.000 GΩ≤ R < 10.000 GΩ:	±(20 % of r	eading + 5 MΩ)		
			10.000 GΩ≤ R < 50.000 GΩ:	±(20 % of r	eading + 50 MΩ)		
	Accuracy *5		50.000 GΩ≤ R ≤ 100.000 GΩ:	±(30 % of r	eading + 200 MΩ)		
	(when GND		100.000 MΩ≤ R < 1.000 GΩ:	±(10 % of r	eading + 0.5 MΩ)		
	is set to Low)	100 nA < i ≤ 200 nA *4	1.000 GΩ≤ R < 2.000 GΩ:	±(10 % of r	eading + 5 MΩ)		
	(i: measured	100 IIA < 1 \(\) 200 IIA 4	2.000 GΩ≤ R < 10.000 GΩ:	±(10 % of r	eading + 10 MΩ)		
	current)(R:		10.000 GΩ≤ R < 50.000 GΩ:	±(10 % of r	eading + 100 MΩ)		
	measurement		10.000 MΩ≤ R < 100.000 MΩ:	±(5 % of re	ading + 0.05 MΩ)		
	resistance)	200 nA < i ≤ 1 µA *4	100.000 MΩ≤ R < 1.000 GΩ:	±(5 % of re	ading + 0.5 MΩ)		
		200 ΠΑ < Γ ≤ Γ μΑ 4	1.000 GΩ≤ R < 10.000 GΩ:	±(5 % of re	ading + 5 MΩ)		
			10.000 GΩ≤ R < 25.000 GΩ:	±(5 % of re	ading + 50 MΩ)		
			0.001 MΩ≤ R < 10.000 MΩ:	±(2 % of re	ading + 0.003 MΩ)		
		1 μA < i ≤ 1 mA *3	10.000 MΩ≤ R < 100.000 MΩ:	±(2 % of re	ading + 0.03 MΩ)		
		1 hv < 1 > 1 IIIV 2	100.000 MΩ≤ R < 1.000 GΩ:	±(2 % of re	ading + 0.3 MΩ)		
			1.000 GΩ≤ R < 5.000 GΩ:	±(2 % of re	ading + 3 MΩ)		
	Hold function	<u> </u>	The resistance measurement	after a test is finis	shed is held while the pass ju	dgment is displayed	
	Offset cancel fur	nction	Cancels up to 2000 GΩ of the u	nnecessary insul	ation resistance across output	cables and the like.	OFF function available.

^{*1} Humidity: 70 %rh or less (no condensation), when there is no interference caused by wobbly test leads or other problems.

² If the grounding mode (GND) is set to low in a highly humid environment, leakage current to ground will be generated from the high-voltage wiring sections inside the product and the high-voltage wiring sections between the product and the EUT. This leakage current ranges from several nA to several tens of nA depending on the usage and wiring conditions of the optional TOS9320 high voltage scanner and greatly affects measurement accuracy. The effects of leakage current can be reduced by making measurements with the offset enabled.

^{*3} Add 10 % to the accuracy when measuring 100 V or less.

^{*4} Add 5 % to the accuracy when measuring 100 V or less.
*5 When the measured current is limited to 100 nA or more (no condensation) when the humidity is 50 %rh or less, no external disturbance is present such as swinging test leads, and the offset is enabled.



[Judgment function]

Item			TOS9300	TOS9301	TOS9301PD	TOS9303	TOS9303LC	
Behavior based on judgment					. Buzzer volume level can	be set in the range of		
Benavior based on	juagment		and fail separately. In an	auto test, the buzzer is	s valid only for the judgme	nt that takes place at	the end of the program	
		Judgment method			than or equal to the Uppe	r limit is detected.		
			Judgment is not made do		ne.			
L	JPPER FAIL	Display	11 1 2					
		Buzzer	On					
_		SIGNAL I/O	NAL I/O The Upper-FAIL signal is generated continuously until a STOP signal is received. LOWER FAIL results when a resistance less than or equal to the Lower limit is detected. Judgment is not made during the judgment delay (Judge Delay).					
		Judgment method						
	OWER FAIL	Display	"Lower-FAIL" is displayed		iy (Juuge Delay).			
-	LOWER FAIL	Buzzer	On	u.				
		SIGNAL I/O		s generated continuous	ly until a STOP signal is re	eceived.		
		Judgment method	-		r-FAIL has not occurred w		ses.	
		Display	"PASS" is displayed.					
F	PASS	Buzzer	On (fixed to 50 ms)					
				erated for the length of t	time specified by the Pass	Hold setting.		
		SIGNAL I/O			generated continuously u		received.	
			Monitors the voltage rise	rate during Voltage ris	e time. This is valid when	Auto setting of the jud	dgment delay (Delay A	
Voltage rise rate jud	dgment operation	n		•	ore. The output is shut of	when a judgment is r	nade. Buzzer volume le	
			can be set in the range of					
		Judgment method	When the voltage rise ra		V/s.			
d	dV/dt FAIL	Display	" Lower-FAIL(dv/dt)" is di	isplayed.				
		Buzzer	On					
		SIGNAL I/O			until a STOP signal is rec			
Jpper limit setting r				· · · · · · · · · · · · · · · · · · ·	maximum rated current),			
_ower limit setting r	ange		0.000 MΩ to 99.999 GΩ 500.000 MΩ ≤ R < 1.00	· • ·	maximum rated current),	JFF. Setting 0.000 is	equivalent to OFF.	
		5 - A - C - C - A + 4			setting + 0.51 MΩ)			
		5 nA ≤ i ≤ 50 nA *4	1.000 GΩ ≤ R < 10.000		setting + 15 MΩ)			
			10.000 GΩ ≤ R ≤ 100.00		setting + 210 MΩ)			
		50 nA < i ≤ 100 nA *4	200.000 MΩ ≤ R < 1.000		setting + 0.51 MΩ)			
			1.000 GΩ ≤ R < 10.000		setting + 15 MΩ)			
			10.000 GΩ ≤ R < 50.000		setting + 60 MΩ)			
			50.000 GΩ ≤ R ≤ 100.00	· · · · · · · · · · · · · · · · · · ·	setting + 210 MΩ)			
Accuracy *1 *2 *3			100.000 MΩ ≤ R < 1.00	,	etting + 0.51 MΩ)			
when GND is set to	Guard)	100 nA < i ≤ 200 nA *5	1.000 GΩ ≤ R < 2.00		etting + 15 MΩ)			
i: measured curren			2.000 GΩ ≤ R < 10.00		etting + 20 MΩ)			
R: measurement re	esistance)		10.000 GΩ ≤ R < 50.00	· · · · · · · · · · · · · · · · · · ·	etting + 110 MΩ)			
			10.000 MΩ ≤ R < 100.000		etting + 0.06 MΩ)			
		200 nA < i ≤ 1 μA *5	100.000 MΩ ≤ R < 1.00	· · · · · · · · · · · · · · · · · · ·	etting + 0.51 MΩ)			
		'	1.000 GΩ ≤ R < 10.00	· · · · · · · · · · · · · · · · · · ·	etting + 15 MΩ)			
			10.000 GΩ ≤ R < 25.00		etting + 60 MΩ)			
			0.001 MΩ ≤ R < 10.000	· · · · · · · · · · · · · · · · · · ·	etting + 0.013 MΩ)			
		1 μA < i ≤ 1 mA *5	10.000 MΩ ≤ R < 100.000		etting + 0.04 MΩ)			
			100.000 MΩ ≤ R < 1.00		etting + 0.31 MΩ)			
			1.000 GΩ ≤ R < 5.00		etting + 13 MΩ)			
			500.000 MΩ ≤ R < 1.00		setting + 0.51 MΩ)			
		5 nA ≤ i ≤ 50 nA *4	1.000 GΩ ≤ R < 10.00		setting + 15 MΩ)			
			10.000 GΩ ≤ R ≤ 100.00		setting + 210 MΩ)			
			200.000 MΩ ≤ R < 1.00		setting + 0.51 MΩ)			
		50 nA < i ≤ 100 nA *4	1.000 GΩ ≤ R < 10.00		setting + 15 MΩ)			
			10.000 GΩ ≤ R < 50.00		setting + 60 MΩ)			
Accuracy *6 (when GND is set to Low) (i: measured current) (R: measurement resistance)			50.000 GΩ ≤ R ≤ 100.00		setting + 210 MΩ)			
			100.000 MΩ ≤ R < 1.00		setting + 0.51 MΩ)			
		100 nA < i ≤ 200 nA *5	1.000 GΩ ≤ R < 2.00		setting + 15 MΩ)			
			2.000 GΩ ≤ R < 10.00	· · · · · · · · · · · · · · · · · · ·	setting + 20 MΩ			
			10.000 GΩ ≤ R < 50.00		setting + 110 MΩ)			
			10.000 MΩ ≤ R < 100.000	<u> </u>	etting + 0.06 MΩ)			
		200 nA < i ≤ 1 μA *5	100.000 MΩ ≤ R < 1.00		etting + 0.51 MΩ)			
			1.000 GΩ ≤ R < 10.00		etting + 15 MΩ)			
			10.000 GΩ ≤ R < 25.00	0 GΩ: ±(5 % of se	etting + 60 MΩ)			
			0.001 MΩ ≤ R < 10.000	0 MΩ: ±(2 % of se	etting + 0.013 MΩ)			
		1 11A < j < 1 mA *5	10.000 MΩ ≤ R < 100.000	0 MΩ: ±(2 % of se	etting + 0.04 MΩ)			
1 μA < i ≤ 1 mA *5		I PACT = I IIIA	100.000 MΩ ≤ R < 1.000	0 GΩ: ±(2 % of se	etting + 0.31 MΩ)			
				· · · · · · · · · · · · · · · · · · ·				

^{*1} Making judgments on 200 µA or less requires at least 3 seconds after the rise time ends. Making judgments when the low pass filter is set to on requires at least 10 seconds after the rise time ends.

^{*2} Humidity: 70 %rh or less (no condensation), when there is no interference caused by wobbly test leads or other problems.

^{*3} If the grounding mode (GND) is set to low in a highly humid environment, leakage current to ground will be generated from the high-voltage wiring sections inside the product and the high-voltage wiring sections between the product and the EUT. This leakage current ranges from several nA to several tens of nA depending on the usage and wiring conditions of the optional TOS9320 high voltage scanner and greatly affects measurement accuracy. The effects of leakage current can be reduced by making measurements with the offset enabled.

 $^{^{\}star}4\,$ Add 10 % to the accuracy when measuring 100 V or less.

^{*5} Add 5 % to the accuracy when measuring 100 V or less.

^{*6} When the measured current is limited to 100 nA or more (no condensation) when the humidity is 50 %rh or less, no external disturbance is present such as swinging test leads, and the offset is enabled.

[Timer function]

Item	TOS9300	TOS9301	TOS9301PD	TOS9303	TOS9303LC	
Voltage rise time settings range	0.1 s to 200.0 s					
Test time setting range	0.1 s to 1000.0 s, OFF					
Judgment delay (Judge Delay) setting range *1	0.1 s to 100.0 s, AUTO *2					
Accuracy *3	±(100 ppm of setting +	20 ms)				

[Other specifications]

Item	TOS9300	TOS9301	TOS9301PD	TOS9303	TOS9303LC		
Grounding mode (GND)	Can be switched betw	Can be switched between Low and Guard.					
1		GND is connected to t	he low terminal.				
	Low		Measures the current flowing across the low terminal and chassis (normal applications).				
Guard *1		GND is connected to 0	GND is connected to Guard. Measures only the current flowing through the low terminal (current flowing through the				
	chassis is not measured) (high sensitivity, high accuracy measurement applications).						
Filter function		A low-pass filter can b	A low-pass filter can be inserted into the ammeter measurement circuit. *2				

^{*1} If there is a possibility that the EUT or tools and the like will be grounded or if you are uncertain, do not set GND to Guard. Doing so is extremely dangerous because the ammeter will be shorted and will not be able to measure current. For normal applications, set GND to Low.

^{*1} Less than the sum of the rise time and fall time.
*2 If Delay Auto is set to on, UPPER judgment is not made until the charge time ends.
*3 This excludes fall time.

^{*2} When the low pass filter is on, a judgment delay of at least 5 seconds and a test time are required.



■ Earth Continuity Test

[Output function]

tem			TOS9302	TOS9303	TOS9303LC			
		,	3.0 A to 42.0 A AC/DC	3.0 A to 42.0 A AC/DC				
Current sett	Current setting range *1 Resolution		0.1 A					
		Accuracy	±(1 % of setting + 0.4 A)					
	Maximum rated of	output *2	220 VA (at the output terminal)					
	Distortion		2 % or less (20 A or more, using a 0.1 Ω	2 % or less (20 A or more, using a 0.1 Ω pure resistive load)				
AC	Francis	·	Select 50 Hz or 60 Hz. Sine					
AC	Frequency	Accuracy	±200 ppm					
	Open terminal vo	Itage	6 Vrms or less	6 Vrms or less				
	Output method		PWM switching					
	Maximum rated of	output	220 W (at the output terminal)					
DC	Ripple		±0.4 Ap-p or less (TYP)					
	Open terminal vo	Itage	6.0 V or less	6.0 V or less				

[Measurement function]

Item		TOS9302	TOS9303	TOS9303LC					
	Measurement range	Measurement range 0.0 A to 45.0 A AC/DC							
0	Resolution	0.01 A	0.01 A						
Output ammeter	Accuracy	±(1 % of reading + 0.2 A)							
animeter	Response	AC: RMS value display of average value	response, DC: mean value						
	Hold function	The current measurement after a test is	finished is held while the pass or fail judgr	ment is displayed.					
	Measurement range	AC: 0.00 V to 6.00 V, DC: 0.00 V to 5.50	AC: 0.00 V to 6.00 V, DC: 0.00 V to 5.50 V						
	Resolution	0.001 V	0.001 V						
Output	Offset cancel function	Cancels up to 5 V (AC/DC) of the unnece	Cancels up to 5 V (AC/DC) of the unnecessary voltage from measurements. OFF function available.						
voltmeter	Accuracy	±(1 % of setting + 0.02 V)	±(1 % of setting + 0.02 V)						
	Response	AC: RMS value display of average value	AC: RMS value display of average value response, DC: mean value						
	Hold function	The voltage measurement after a test is	The voltage measurement after a test is finished is held while the pass or fail judgment is displayed.						
	Measurement range *1	1 mΩ to 600 mΩ							
Desistence	Resolution	1 mΩ	1 mΩ						
Resistance meter	Offset cancel function	Cancels up to 10 Ω of the unnecessary r	Cancels up to 10 Ω of the unnecessary resistance from measurements. OFF function available.						
IIICICI	Accuracy	±(2 % of reading + 3 mΩ)	$\pm (2 \% \text{ of reading} + 3 \text{ m}\Omega)$						
	Hold function	The resistance measurement after a test is finished is held while the pass judgment is displayed.							

^{*1} Calculated from the measured output voltage and measured output current.

[Judgment function]

Item			TOS9302	TOS9303	TOS9303LC		
			Buzzer volume level can be set in the ra	ng voltage can be selected. The output is s inge of 0 (OFF) to 10 for pass and fail sepa or the judgment that takes place at the end	rately.		
		Judgment method	UPPER FAIL results when a resistance greater than or equal to the Upper limit is detected or when a sensing voltage is detected. Judgment is not made during a contact check.				
	UPPER FAIL	Display	"U-FAIL" is displayed.				
		Buzzer	On				
		SIGNAL I/O	The U-FAIL signal is generated continue	ously until a STOP signal is received.			
Behavior based on judgment		Judgment method	LOWER FAIL results when a resistance is detected.	less than or equal to the lower limit (Lower	r) is detected or when a sensing voltage		
	LOWER FAIL	Display	"L-FAIL" is displayed.				
		Buzzer	On				
		SIGNAL I/O	The L-FAIL signal is generated continuo	ously until a STOP signal is received.			
		Judgment method	PASS judgment is made if U-FAIL or L-F	AIL has not occurred when the test time e	lapses.		
		Display	"PASS" is displayed.				
	PASS	Buzzer	On (fixed to 50 ms)				
		SIGNAL I/O		ngth of time specified by the Pass Hold set signal is generated continuously until a STO	•		
	Upper limit settin	g range	0.0001 Ω to 10.0000 Ω	,			
Resistance	Lower limit settin	g range	0.0000 Ω to 9.9999 Ω				
judgment	Judgment accura	acy	$\pm (2\% \text{ of setting} + 3 \text{ m}\Omega)$				
	Upper limit settin	g range	0.001 V to 5.000 V AC/DC				
Voltage	Lower limit settin	g range	0.000 V to 4.999 V AC/DC				
judgment	Judgment accura	асу	±(2 % of setting + 0.05 V)				
Calibration	-	·	Calibrated using a pure resistive load (with the rms of a sine wave for AC)				
Contact check fu	ınction		Checks that current flows through the te	est leads and then starts the test. (OFF sett	ing available)		

[Timer function]

Item	TOS9302	TOS9303	TOS9303LC		
Current rise time settings range	0.1 s to 200.0 s				
Current fall time setting time *1	0.1 s to 200.0 s, OFF				
Test time	0.1 s to 1000.0 s, OFF				
Accuracy	±(100 ppm of setting + 20 ms) (excluding the fall time)				

^{*1} This setting is used only when a PASS judgment occurs. During a DC test, the voltage may not drop all the way within the set time because of the electrostatic capacity inside the product and the EUT.

^{*1} No greater than the maximum rated output and resistance no greater than the output terminal voltage 5.4 V.
*2 When tests are performed consecutively, output time limit and rest time may become necessary depending on the upper limit setting.

■ Partial Discharge Test

[Output function]

Item			TOS9301PD	
			0.050 kV to 5.000 kV	
	Output range	Resolution	1V	
		Setting accuracy	±(1.2% of setting + 0.02kV) (at no load)	
	Max. rated load		250 VA (5 kV/ 50mA)	
	Max. rated current		50 mA (when the output voltage is 0.2 kV or higher)	
AC output	Output voltage		Sine	
section	waveform*1	Distortion	2 % or less. (when the output voltage is 0.5 kV or higher and no load or a pure resistive load is connected)	
	Crest factor		√2 ± 3 % (800 V or higher)	
	Fraguenau		50 Hz/60 Hz	
	Frequency	Accuracy	±0.1 %	
	Voltage regulation		±3 % or less (when changing from maximum rated load to no load)	
	Output method		PWM switching	
Output voltage	monitor function		If the output voltage exceeds ±(10 % of setting + 0.05 kV), the output is turned off, and the protection function is activated.	

^{*1} If an AC voltage is applied to a capacitive load, the output voltage may rise higher than at no load depending on the load capacitance. Further, waveform distortions may occur if an EUT whose capacitance is dependent on voltage (for example, an EUT that consists of ceramic capacitors) is connected as the load. However, if the test voltage is 1.5kV, the effect of a capacitance of 1 000pF or less can be ignored. Because the product's high-voltage power supply uses the PWM switching method, if the test voltage is 500 V or less, the switching and spike noise proportions are large. The lower the test voltage, the greater the waveform is distorted.

[Measurement function]

Item			TOS9301PD		
	Measurement range		0.00 kV to 7.50 kV AC/DC		
	Resolution		0.1 V		
√oltmeter	Accuracy *1		±(1.2 % of reading + 5 V)		
	Response		Can be switched between true rms and peak-value response.		
	Hold function		The voltage measurement after a test is finished is held while the pass/fail judgment is displayed.		
	Electric charge meas	surement method	Adopts the measurement principles specified in IEC 60664-1 Edition 3.0 *2		
	Measurement range		0 pC to 10000 pC		
	Measurement	100pC range	0.1 pC		
	resolution	1000pC range	0.1 pC		
	resolution	10000pC rang	1 pC		
	Accuracy *1 *3	100pC range	±(5 % of full scale + 7 pC)		
		1000pC range	±(5 % of full scale)		
		10000pC rang	±(5 % of full scale)		
	Measurement interval		Determined based on the measured values in each cycle of an applied voltage.		
	Hold function		The electric charge after a test is finished is held while the pass judgment is displayed.		
Electric charge	Maximum electrosta	tic capacity of the EUT	10 nF		
measurement	Peak hold function		Holds the maximum value during a measurement.		
	Filter function		A low-pass filter can be inserted into the electric charge measurement circuit.		
	Discharge inception cutoff voltage measu		Measures the voltage at which discharge exceeding a preset electric charge starts and the voltage at which discharge ceases (complies with IEC60664-1 third edition).		
	Calibration (Precalib		Calibrate using the built-in calibration capacitor (1000 pF).		
	Pulse counting function Upper limit setting range		Counts the number of pulses that have passed through the high-pass filter and makes a FAIL judgment if the count exceeds the upper limit.		
			1 to 100000		
	BPF characteristics		Can switch the characteristics of the band-pass filter in the electric charge measuring circuit		
	switching function	Center frequency	100 kHz / 160 kHz / 300 kHz		
	Coupling capacitor		0.01 µF		

^{*1} When the pulse interval is 200 μs or more

^{*2} Can be used to conduct tests based on the principles of IEC 60664-1 Edition 3.0, including the test circuit (for earthed test specimen) and the test voltages. However, does not fully meet the accuracy requirements.

^{*3} When Band Pass Filter is set to 160 kHz.



[Judgment function]

				TOS9301PD
Item				11111
Electric discharg	e judgment			The output is shut off when a judgment is made.
			Judgment method	A current higher than or equal to the upper limit is measured.
	UPPER FAI	L	Display	"Upper-FAIL (Current)" is displayed.
	(Current)		Buzzer	On
			SIGNAL I/O	The Upper-FAIL signal is generated continuously until a STOP signal is received.
			Judgment method	An electric charge greater than or equal to the upper limit is measured.
	UPPER FAI	L	Display	"Upper-FAIL (Coulomb)" is displayed.
	(Coulomb)		Buzzer	On
	SIG		SIGNAL I/O	The Upper-FAIL signal is generated continuously until a STOP signal is received.
	Judgment method		Judgment method	A discharge pulse count greater than or equal to the upper limit is measured.
	UPPER FAI	L	Display	"Upper-FAIL (Pulse)" is displayed.
	(Pulse)		Buzzer	On
			SIGNAL I/O	The Upper-FAIL signal is generated continuously until a STOP signal is received.
			Judgment method	Upper-FAIL does not happen after the test time has elapsed.
			Display	"PASS" is displayed.
	PASS		Buzzer	On
			SIGNAL I/O	The PASS signal is generated for the length of time specified by the Pass Hold setting. If Pass Hold is set to Infinity, the PASS signal is generated continuously until a STOP signal is received.
Upper current lim	nit			50 mA (with no calibration)
Upper limit of ele	Upper limit of electric charge Setting range		g range	1 pC to 10000 pC
(Upper Coulomb)	(Upper Coulomb) Accurac		acy	As per the accuracy of electric charge measurement
	Pulse count judgment criteria (Upper Pulse Count) setting range			1 to 100000 (with no calibration)

[Timer function]

Item	TOS9301PD
Voltage rise time (Rise Time) setting range	0.1 s to 200.0 s
Voltage fall time (Fall Time) setting range *1	0.1 s to 200.0 s, OFF
Test time setting range	0.1 s to 1000.0 s, OFF
Accuracy	±(100 ppm of setting + 20 ms) (excluding Fall Time)

^{*1} This setting is used only when PASS judgment occurs.

[Other specifications]

r	- 4	
Item		TOS9301PD
Analog monitor *1		Outputs a voltage signal according to the current waveform, voltage waveform, or electric discharge waveforms.
	V	Voltage waveform: Scale 1 kV/1 V
	Qpd *2	Electric discharge: Full scale of the scale measurement range/10 V
	Ipd *3	Partial discharge current waveform

^{*1} Monitor signal output is isolated from the chassis (earth).

^{*2} During PD tests, the monitor signal common is connected to the chassis (ground). The Qpd waveforms are the ones output from the peak detection circuit and are reset after each cycle. The lpd waveforms are the discharged ones after passing through the filter in the measurement section of the TOS93 series. Therefore, the scale varies depending on the frequency characteristics of the actual discharge waveform.

^{*3} The lpd waveforms are the ones that can be obtained after the actual discharge waveforms have passed the TOS9301PD measurement filter. Therefore, the scale varies according to the frequency response of the discharge waveform.

■ Leakage Current Test

[Measurement function]

Item				TOS9303LC			
	TC			Touch current measurement			
		Measurement	mode	Uses a measurement circuit network representing the impedance of a human body and measures the voltage drop across a reference resistance to calculate the touch current.			
		Deska	Enc - Pe	A terminal: measurement terminal (for connecting to the enclosure of the EUT) B terminal: open			
		Probe settings	Enc - Enc	A and B terminals: measurement terminal (for connecting to the enclosure of the EUT)			
		settings	Enc - Liv	A terminal: measurement terminal (for connecting to the enclosure of the EUT)			
			Enc - Neu	B terminal: open			
				Protective conductor current measurement			
Measurement	PCC	Measurement method		Measures the voltage drop across a reference resistance inserted in the middle of the protective ground line to calculate			
Item		Measurement	memou	the protective conductor current. The measurement impedance is 150 Ω .			
		Patient Measurement method		Patient leakage current measurement			
	Patient			Uses a network conforming to IEC 60601 and measures the voltage drop across a reference resistance to calculate patient leakage current.			
				Measures the current flowing or voltage applied across the A and B terminals (simultaneous measurement not possible).			
	Meter		Current	Uses a measurement circuit network representing the impedance of a human body and measures the voltage drop			
	INICICI	Measurement	measurement	across a refer-ence resistance to calculate the current flowing across the A and B terminals.			
		method	Voltage	Measures the voltage applied across the A and B terminals.			
			measurement	measures the voltage applied across the A and B terminals.			
	DC		DC	Eliminates AC components and measures only the DC component.			
Current measur	ement mo	de	RMS	Measures the true rms value (switch AC and AC+DC)			
			Peak *1	Measures waveform peak values			

^{*1} Current measurements may not be stable due to the effects of the power supply line waveform or the wiring environment between the product and the EUT.


[Measurement circuit network]

Item	Item		TOS9303LC			
	A (IEC 6099	90 compliant) *1	(1.5 k Ω // 0.22 μ F) + 500 Ω , reference measurement element: 500 Ω			
	B (IEC 60990 compliant)		(1.5 k Ω // 0.22 μ F) + 500 Ω // (10 k Ω + 22 nF), reference measurement element: 500 Ω , voltage measurement U1 and U3 switchable			
	C (IEC 6099	90 compliant)	(1.5 k Ω // 0.22 μ F) + 500 Ω // (10 k Ω + (20 k Ω + 6.2 nF) // 9.1 nF), reference measurement element: 500 Ω , voltage measurement U1 and U3 switchable			
	D (Electrical Act, etc.)	Appliances and Materials Safety	1 kΩ, reference measurement element: 1 kΩ			
Network	E (Electrical Act)	Appliances and Materials Safety	1 k Ω // (10 k Ω + 11.225 nF + 579 Ω), reference measurement element:1 k Ω			
	F (UL and the	e like)	$1.5~k\Omega$ // $0.15~\mu F$, reference measurement element: $1.5~k\Omega$			
	G		$2 \text{ k}\Omega$, reference measurement element: $2 \text{ k}\Omega$			
	H (IEC 6101	0-1)	375 Ω // 0.22 μF + 500 Ω , reference measurement element: 500 Ω			
	I (Patient, IE	C60601-1wet)	1 kΩ // 10 kΩ + 0.015 μF, reference measurement element: 1 kΩ			
	J (through)		For voltmeter calibration			
	PCC-1		150 Ω , reference measurement element: 150 Ω			
	PCC-2 (IEC	60598-1)	150 Ω // 1.5 μ F, reference measurement element: 150 Ω			
Network constar	Network constant tolerance		Resistance: ±0.1 %, capacitor 0.15 µF: ±2 %, others: ±1 %			
		A, B, C, H	Input voltage vs. output voltage ratio: logical value ± 5 %(according to IEC 60990 Annex L and F)			
Notwork accura		E	Input voltage vs. output voltage ratio: logical value ± 5 %			
Network accuracy		D, G	Reference measurement element (resistance) ± 1 %			
		I	Input voltage vs. output voltage ratio: logical value ± 5 %			


^{*1} Current measurements may not be stable due to the effects of the power supply line waveform or the wiring environment between the product and the EUT.




Measurement circuit network
 (NetworkA IEC 60990 Fig. 3 U1 measurement)




 Measurement circuit network (NetworkB-U1 IEC 60990 Fig. 4 U2 measurement)




 Measurement circuit network (NetworkB-U2 IEC 60990 Fig. 4 U1 measurement)




 Measurement circuit network (NetworkC IEC 60990 Fig. 5 U3 measurement)




 Measurement circuit network
 (NetworkD Electrical Appliances and Materials Safety Act single frequency)




 Measurement circuit network
 (NetworkE Electrical Appliances and Materials Safety Act multiple frequencies)




 Measurement circuit network (NetworkF IEC 61029, UL)




 Measurement circuit network (NetworkG IEC 60745)




 Measurement circuit network (Networkl IEC 60601-1)



 Measurement circuit network (NetworkPCC-1)



 Measurement circuit network (NetworkPCC-2 IEC60598-1)



[Measurement section] The range varies by network.

Item				TOS9303LC			
	Range 1			DC, RMS: 1.00 μA(min.) to 200.00 μA(max), Peak: 1.00 μA(min.) to 282.00 μA(max)			
	Range 2			DC, RMS: 12.50 μA(min.) to 2000.0 μA(max), Peak: 17.50 μA(min.) to 2830.0 μA(max)			
	Range 3			DC, RMS: 125.0 µA(min.) to 20.000 mA(max), Peak: 175.0 µA(min.) to 28.300 mA(max)			
	Range 4			DC, RMS: 1.250 mA(min.) to 100.00 mA(max), Peak: 1.750 mA(min.) to 100.00 mA(max)			
	Danasau	itabina		Auto or Fix selectable. If a measurement falls outside the measurement range of each range, the measurement			
Magaurament range	Range sw	ritching		value blinks as a warning.			
Measurement range	Auto			The range is set automatically according to the measurements.			
		Fix		For TC and PCC measurements, the measurement range is selected automatically according to the UPPE			
		I IX		value. For meter measurements, the range is fixed to the specified range.			
	Bandwidth	h switchii	na	Can be expanded to a bandwidth that allows measurements from 0.1 Hz, which is required in the			
				measurement of medical instruments and the like.			
		Norma		Normal measurement bandwidth: 15 Hz to 1 MHz			
		Expand	1	Expands the measurement range to 0.1 Hz to 1 MHz			
		DC	T	$\pm (5.0 \% \text{ of reading} + 2 \mu\text{A})$			
			0.1 Hz ≤ f < 15 Hz	±(10.0 % of reading + 2 μA)			
		RMS	15 Hz ≤ f ≤ 100 kHz	$\pm (7.0 \% \text{ of reading} + 2 \mu\text{A})$			
	Range 1		100 kHz < f ≤ 1 MHz	±(10.0 % of reading + 2 μA)			
	. 3		0.1 Hz ≤ f < 15 Hz	±(10.0 % of reading + 10 µA)			
		Peak	15 Hz ≤ f ≤ 1 kHz	±(10.0 % of reading + 10 μA)			
			1 kHz < f ≤ 100 kHz	±(10.0 % of reading + 10 μA)			
		100 kHz < f ≤ 1 MHz		±(20.0 % of reading + 10 μA)			
	Range 2	DC		$\pm (5.0 \text{ % of reading} + 20 \mu\text{A})$			
		RMS	0.1 Hz ≤ f < 15 Hz	±(10.0 % of reading + 10 µA)			
			15 Hz ≤ f ≤ 100 kHz	±(7.0 % of reading + 8 μA)			
			100 kHz < f ≤ 1 MHz	±(10.0 % of reading + 10 μA)			
		Peak	0.1 Hz ≤ f < 15 Hz	±(10.0 % of reading + 10 μA)			
			15 Hz ≤ f ≤ 1 kHz	±(10.0 % of reading + 10 μA)			
Total accuracy *2			1 kHz < f ≤ 100 kHz	±(10.0 % of reading + 10 μA)			
(when network A, B,			100 kHz < f ≤ 1 MHz	±(20.0 % of reading + 10 µA)			
or C is used) *3		DC	T	±(5.0 % of reading + 50 μA)			
,		0.1 Hz ≤ f < 15 Hz		±(10.0 % of reading + 20 µA)			
		RMS	15 Hz ≤ f ≤ 100 kHz	$\pm (7.0 \% \text{ of reading} + 20 \mu\text{A})$			
	Range 3		100 kHz < f ≤ 1 MHz	±(10.0 % of reading + 20 µA)			
			0.1 Hz ≤ f < 15 Hz	±(10.0 % of reading + 50 µA)			
		Peak	15 Hz ≤ f ≤ 1 kHz	$\pm (7.0 \% \text{ of reading} + 50 \mu\text{A})$			
			1 kHz < f ≤ 100 kHz	±(10.0 % of reading + 50 µA)			
			100 kHz < f ≤ 1 MHz	±(20.0 % of reading + 50 μA)			
		DC	T	±(5.0 % of reading + 0.5 mA)			
			0.1 Hz ≤ f < 15 Hz	±(10.0 % of reading + 0.2 mA)			
		RMS	15 Hz ≤ f ≤ 100 kHz	±(7.0 % of reading + 0.2 mA)			
	Range 4		100 kHz < f ≤ 1 MHz	±(10.0 % of reading + 0.2 mA)			
			0.1 Hz ≤ f < 15 Hz	±(10.0 % of reading + 0.5 mA)			
		Peak	15 Hz ≤ f ≤ 1 kHz	±(7.0 % of reading + 0.5 mA)			
			1 kHz < f ≤ 100 kHz	±(10.0 % of reading + 0.5 mA)			
			100 kHz < f ≤ 1 MHz	±(20.0 % of reading + 0.5 mA)			
nput resistance				1 ΜΩ ± 1 %			
nput capacitance				200 pF or less (internal voltmeter input capacitance: 100 pF or less)			
Common mode rejection	on ratio			10 kHz or less: 60 dB or more, 10 kHz to 1 MHz: 40 dB or more			
Offset cancel function				Cancels up to 10 mA of the unnecessary current from measurements. OFF function available.			

^{*1} Voltmeter band expansion is possible when network I is selected.

If a network other than A, B, C or H is used, calculate as follows: For Network D, E, or I, the \blacksquare part of $\pm(\Box\%$ of reading + \blacksquare A) is half the value.

For F, the ■ part is one-third the value.

For G, the part is one-fourth the value.

For PCC-1 or PCC-2, the ■ part is 3.3 times the value.

^{*2 0.1} Hz ≤ f < 15 Hz is for when voltmeter band expansion (VoltMeter BandWidth) is set to Expand. Requires at least 120 second of test time.

^{*3} A value converted to current for measurements using Network A, B, C or H with voltmeter accuracy of this product as the reference.



[Judgment function] The range varies by network.

Item			TOS9303LC
			Judgment starts after the judgment delay (Judge Delay). Buzzer volume level can be set in the range of 0 (OFF) to 10 for pass and fail separately. In an auto test, the buzzer is valid only for the judgment that takes place at the end of the program.
		Judgment method	UPPER FAIL results when a current greater than or equal to the upper limit (Upper) is detected.
	UPPER FAIL	Display	"Upper-FAIL" is displayed.
	OFFERFAIL	Buzzer	On
		SIGNAL I/O	The Upper-FAIL signal is generated continuously until a STOP signal is received.
Behavior based		Judgment method	LOWER FAIL results when a current less than or equal to the lower limit (Lower) is detected.
on judgment	LOWER FAIL	Display	"Lower-FAIL" is displayed.
onjudgment	LOWER FAIL	Buzzer	On
		SIGNAL I/O	The Lower-FAIL signal is generated continuously until a STOP signal is received.
		Judgment method	PASS judgment is made if Upper-FAIL or Lower-FAIL has not occurred when the test time elapses.
		Display	"PASS" is displayed.
	PASS	Buzzer	On (fixed to 50 ms)
		SIGNAL I/O	The PASS signal is generated for the length of time specified by the Pass Hold setting. If Pass Hold is set to Infinity, the PASS signal is generated continuously until a STOP signal is received.
	RANGE 1		DC, RMS: 0.1 μA(min.) to 200 μA(max), Peak: 0.1 μA(min.) to 282 μA(max)
Upper Setting	RANGE 2		DC, RMS: 15.1 μA(min.) to 2.00 mA(max), Peak: 21.3 μA(min.) to 2.83 mA(max)
range	RANGE 3		DC, RMS: 151 μA(min.) to 20.00 mA(max), Peak: 213 μA(min.) to 28.3 mA(max)
	RANGE 4		DC, RMS: 1.51 mA(min.) to 100 mA(max), Peak: 2.13 mA(min.) to 100 mA(max)
Lower Setting ra	nge		A value that is -1 digit from the upper setting range.
Judgment accura	асу		Conforms to total accuracy(Read "reading" as "upper setting" of total accuracy.)

[Timer function]

Item		TOS9303LC
Ludament delevi (ludas Delevi)	Setting range	1.0 s to 1000.0 s, OFF
Judgment delay (Judge Delay)	Accuracy	±(100 ppm of setting + 20 ms)
Toot time	Setting range	1.0 s to 1000.0 s, OFF
Test time	Accuracy	±(100 ppm of setting + 20 ms)

[Other specifications]

Item			TOS9303LC			
			Displays the estimated current converted with the preset supply voltage (Conv Voltage), based on the voltage supplied to			
Voltage conversion			the EUT and the measured current. (This is invalid in meter mode.)			
voitage convers	1011	Setting range	80.0 V to 300.0 V, OFF			
Resolution		Resolution	0.1 V			
Power supply lin	e polarity selection		Set the polarity of the power supply line to supply to the EUT to positive or negative.			
Single fault mod	e (Condition) selecti	on	Set the EUT single fault mode to normal, neutral line disconnection (Fault Neu), or protective ground wire disconnection (Fault PE).			
Ground check			In the touch current test between the enclosure and power supply line, if the EUT enclosure is grounded, Contact-FAIL occurs.			
Measurement cl	neck		Checks the measurement function by shorting across the A and B terminals. If an error is found, the protection function is activated.			
		Measurement range	80.0 V to 250.0 V			
	measurementAC	Resolution	0.01 V			
LINE (EUT)		Accuracy	±(3 % of reading + 1 V)			
		Measurement range	0.1 A to 15.00 A			
,	neasurementAC	Resolution	0.001 A			
LINE (EUT)		Accuracy	±(5 % of reading + 30 mA)			
_		Measurement range	10 W to 1500 W			
Power measure	ment(active power)	Accuracy	±(5 % of reading + 8 W) (with the supply voltage at 80 V or more, at a load power factor of 1)			
		DC	10.00 V to 300.0 V			
	Measurement	RMS	10.00 V to 300.0 V			
Voltage	range	Peak	15.00 V to 430.0 V			
measurement	Input impedance		Approx. 40 MΩ			
across the A	Accuracy *1		±(3 % of reading + 2 V) (measurement range fixed to AUTO)			
and B termi- nals	SELV detection	,	Set a voltage for detecting SELV. When the value is exceeded, the DANGER LED lights.			
ilais		Setting range	10.0 V to 99.9 V, OFF			
		Resolution	0.1 V			
		Between the A and B terminals	250 V			
Measurement	Rated voltage	Between the terminals and chassis	250 V			
terminal	Rated current		100 mA			
	Measurement cate	gory	CAT-II			
	Valid terminal disp	• .	Terminals valid for measurement are indicated on the display.			
	110% terminal	•	Terminal for supplying 110% voltage of the AC line.			
	Nominal voltage ra	inge	100 V to 240 V, 50 Hz/60 Hz			
Power supply	Input voltage range	e	85 Vac to 250 Vac			
for the EUT	Rated output capa		1500 VA			
	Maximum operatin	•	15 A (Overcurrent protection is activated at approximately 15.7 A.)			
	Inrush current	J	70 Apeak max. (within 20 ms)			

^{*1} If voltage is measured with the A and B terminals open, measurements will be easily affected by induced voltage.

■ Interface (Common)

Item			TOS9300	TOS9301	TOS9301PD	TOS9302	TOS9303	TOS9303LC	
REMOTE		MINI DIN 9-pin connector. Connect the following option to remotely control the starting and stopping of tests. Remote control box RC01-TOS, RC02-TOS High voltage test probe HP01A-TOS, HP02A-TOS (when the test voltage is 4 kVac 5 kVdc or less)							
SIGNAL I/O			D-sub 37-pin conne	ector. For the pin arra	ngement				
	Function		Enable/disable interlock, recall setup memories, recall auto test programs, start/stop testing, monitor the test and voltage generation status, monitor the test status, monitor judgment results, monitor the step execution status of auto tests, monitor the activation status of protection functions The input signals are all low-active control. The input terminal is pulled up to +12 V by a resistor.						
	Input specifica	tions	Leaving the input to	erminal open is equiva	alent to applying a hig	h level signal.			
		High-level input voltage	11 V to 15 V						
		Low-level input voltage	0 V to 4 V						
		Low-level input current	-5 mA max.						
		Input time width	5 ms min.						
		Output method	Open collector output (4.5 Vdc to 30 Vdc)						
Outp	Output	Output withstanding voltage	30 Vdc						
	specifications	Output saturation voltage	Approx. 1.1 V (25 °C, 77 °F)						
		Maximum output current	400 mA(TOTAL)						
STATUS OUT	Function		Output terminal of an option product.						
	Positive termin	nal (red)	Outputs +24 V. Max	ximum output current	100 mA.				
	Negative term	nal (black)	+24 V circuit common.						
SCANNER			MINI DIN 8-pin connector. Terminal for the optional TOS9320 high voltage scanner. The maximum number of connections is 4 devices(16 channels).						
USB (host)			Standard type A socket Complies with the USB 2.0 specifications; data rate: 12 Mbps (full speed)						
Remote control	Function		All functions except	t turning on and off th	e power, key lock, and	d auto test can be re	motely controlled.		
	RS232C	Hardware	Baud rate: 9600, 19	ctor (EIA-232D comp 9200, 38400, 57600, stop bits: 1 bit; parity	115200 bps	I: none/CTS-RTS			
	LIOD (desided)	Hardware	Standard Type B co	onnector. Complies w	ith the USB 2.0 speci	fications; data rate: 4	180 Mbps (high spe	ed)	
	USB (device)	Device class	Complies with the U	JSBTMC-USB488 de	vice class specification	ons.			
		Hardware	IEEE 802,3 100Bas	se-TX/10Base-T Ethe	rnet. Auto-MDIX com	pliant.IPv4, RJ-45 c	onnector.		
	LAN	Compliant standards	LXI Class C, Specif	fication 1.5					
		Communication protocol	VXI-11, HISLIP, SC	PI-RAW					
Display			7-inch LCD. Display	ys settings, measured	values, judgment res	sults, ets.			

■ Other Functions (Common)

Item		TOS9300	TOS9301	TOS9301PD	TOS9302	TOS9303	TOS9303LC		
Auto test		Auto execution by o	Auto execution by combining ACW, DCW, IR, and EC. For LC, a combination is possible only using TC, PCC, and Patient.						
T4	Setup memory		ions (ACW, DCW, IR	EC, PD, LC) can be	saved.				
Test condition memory	Program memory	Up to 25 program (ACW, DCW, IR, EC, PD) combinations, each containing 100 steps, can be saved							
memory	Program memory (LC)	Up to 24 program (TC, PCC, Patient) cor	nbinations, each co	ntaining 100 steps, ca	an be saved.			
Test result men	nory		latest test result of in saved in CSV format	•		re cleared when the p	power is turned off.		
System clock		For recording the ca	alibration time and te	st times					
	Recordable time	Up to year 2038							
	Calibration period setting	Displays a warning at power-on when the specified period passes. Select whether to activate a protection function or only display a warning in the display area when a warning occurs.							
Measurement d	lisplay	Maximum and mini	mum measurements	can be displayed.					
	Normal	Displays measurements during a test. Maximum and minimum values are not held.							
	Maximum and minimum value display	Displays the maximum current measurement for withstanding voltage (ACW/DCW) tests, the minimum resistance measurement for insulation resistance (IR) tests, the resistance measurement or voltage measurement for earth continuity (EC) tests.							
Test start	Double Action	When you press STOP, "READY" is shown for 0.5 seconds. A test starts only when you press START within this period.							
method	Momentary	Tests are only executed while the START switch is held down.							
Start Long		A test starts only when the START switch is held down for at least 1 second.							
PASS judgment display time (Pass Hold)		Set the time to hold the pass judgment result display (0.05 s to 10.00 s) or hold it until STOP is pressed (Infinity).							
STOP signal disable (Fail Mode)		It is possible to set the instrument so that fail judgment results and PROTECTION mode cannot be released from a device connected to the SIGNAL I/O connector or REMOTE connector.							
Key lock		Lock the operation of the keys to prevent changing the settings or overwriting memory or programs by mistake.							



■ Other Functions (Common)

Item		TOS9300 TOS9301 TOS9301PD TOS9302 TOS9303 TOS9303	3LC					
		If a protection function is activated during a test, the output is shut off and the test is stopped immediately. In an LC te						
Protection	functions	the power supply to the EUT is stopped, and the A and B terminals are opened. Conditions that cause a protection fur	nction					
		to be activated are as follows.						
	Interlock	Interlock is activated.						
	Power Supply	There is an error in the power supply section.						
	Output Error	An output voltage outside of the following range is detected.						
	Output Error	ACW, DCW, IR test, PD test: ±(10 % of setting + 50 V), EC test: ±(10 % of setting + 2 A)						
		An output power or output current outside of the following range is detected.						
	Over Load	ACW: 550 VA, DCW: 110 W or 50 mA, IR (7200 V test): 110 W or 25 mA, IR (-1000 V test): 2 mA, EC: 240 VA, LC: AC	CLINE					
		OUT current at approx. 15.7 A or power at 1600 VA.						
	Over Heat	The internal temperature of the product is abnormally high.						
	Over Rating	During a withstanding voltage test, an output current is generated for a length of time that exceeds the output time lim	mit.					
	Cal	The preset calibration period is exceeded.						
	Remote	The REMOTE connector is connected or disconnected.						
	Signal I/O	There is a change in the SIGNAL I/O connector's ENABLE signal.						
	Communication	An internal communication error is occurring.						
	Over Range	A value exceeding the maximum value of the measurement range is detected.						
	Measure	An error is detected in the LC test measurement check.						
Short		A relay operation error is detected in an LC test.						
	Earth Fault	When the grounding mode (GND) is set to Guard, abnormal current flows from the high voltage output of this product	t to					
	Earth Fault	ground.						
	Scan I/F	While scanning, the interface cable is disconnected. Or, the channel-assigned scanner is not detected.						

■ General Specifications (Common)

tem			TOS9300	TOS9301	TOS9301PD	TOS9302	TOS9303	TOS9303LC			
Backup battery	life		3 years (at 25 °C)								
	Installation location			Indoors, 2000 m or less							
Environment	Spec guara-	Temperature	5 °C to 35 °C (41 °F to 95 °F)(18 °C to 28 °C for partial discharge tests)								
	nteed range	Humidity	20 %rh to 80 %rh (20 %rh to 70 %rh for partial discharge tests)(no condensation)								
	Operating	Temperature	0 °C to 40 °C (32 °F to 104 °F)								
	rang	Humidity	20 %rh to 80 %rh (r	20 %rh to 80 %rh (no condensation)							
	Storage	Temperature	-20 °C to 70 °C (-4	°F to 158 °F)							
	range	Humidity	90 %rh or less (no	condensation)							
	Nominal voltage (allowable voltage)		100 Vac to 120 V, 2	00 V to 240 V (90 Va	ac to 132 V, 170 V to 25	60 V)					
Power supply	Power	No load(READY state)	100 VA or less								
	consumption	Rated load	800 VA max.								
	Allowable freq	uency range	47 Hz to 63 Hz								
Insulation resist	ance (between a	AC LINE and chassis)	30 MΩ or more (500	0 Vdc)							
Withstanding vo	Itage (between	AC LINE and chassis)	1500 Vac, 1 minute	1500 Vac, 1 minute, 20 mA or less							
Earth continuity			25 Aac, 0.1 Ω or less								
Weight			TOS9300:Approx. 17 kg (37.5lb.), TOS9301:Approx. 18 kg (39.7lb.), TOS9301PD:22 kg (48.5lb.),								
weight			TOS9302:Approx. 20 kg (44.1lb.), TOS9303:Approx. 21 kg (46.3lb.), TOS9303LC:Approx. 22 kg (48.5lb.)								
			1 ' ' '	•	attached power cord va		•	,.			
			0	` '	r), SIGNAL I/O plug (1	,, 0	arning sticker (1 pc.),			
Accessories			, , ,	***	, Safety Information (1	1 2 /-					
			1 ' '		included with the TOS	**	2021 C anlu				
				Test leads for earth continuity test: TL13-TOS (1 pair., *TOS9302, TOS9303, TOS9303LC only),							
			[TOS9303LC only: Spare fuse (1 pc.), Test leads for leakage current test (2 red, 1 black), Flat probe (1 sheet)] Complies with the requirements of the following directive and standards.								
			EMC Directive 2014	•	ollowing directive and s	stanuarus.					
Electromagnetic compatibility *1 *2					ass A *3, Group 1 *4), E	EN 61000-3-2. EN 6	1000-3-3				
			,	e following condition		, , ,					
			The maximum leng	th of all cabling and	wiring connected to the	e product must be le	ss than				
				les are being used v	hen using the SIGNAL	I/O.The high-voltag	ge test lead				
				.Electrical discharge	s are applied only to the	ne EUT.					
Safety *1	Cofeb. #4				ollowing directive and						
Salety I			Low Voltage Directi	ive 2014/35/EU *2, E	N 61010-1 (Class I *5	, Pollution Degree 2	*6), EN 61010-2-03	0			

- *1 Does not apply to specially ordered or modified products.
- *2 Only on models that have CE/UKCA marking on the panel.
- *3 This is a Class A instrument. This product is intended for use in an industrial environment. This product may cause interference if used in residential areas. Such use must be avoided unless the user takes special measures to reduce electromagnetic emissions to prevent interference to the reception of radio and television broadcasts.
- *4 This is a Group 1 instrument. This product does not generate and/or use intentionally radio-frequency energy, in the form of electromagnetic radiation, inductive and/or capacitive coupling, for the treatment of material or inspection/analysis purpose.
- *5 This is a Class I instrument. Be sure to ground this product's protective conductor terminal. The safety of this product is guaranteed only when the product is properly grounded.
- *6 Pollution is addition of foreign matter (solid, liquid or gaseous) that may produce a reduction of dielectric strength or surface resistivity. Pollution Degree 2 assumes that only non-conductive pollution will occur except for an occasional temporary conductivity caused by condensation.

■ High Voltage Scanner

[Basic specifications]

Item		TOS9320			
Maximum aparating valtage	AC	5 kV			
Maximum operating voltage	DC	7.2 kV			
Number of channels		4 (Each channel can be set to high, low, or open.)			
		4 units			
Maximum connections		Channel numbers are assigned according to the order in which connections are made to the TOS9300 series test			
		1st scanner: CH1 to CH4, 2nd scanner:CH5 to CH8, 3rd scanner: CH9 to CH12, 4th scanner: CH13 to CH16			
Contact check function		Available			
	DANGER	Lights up in sync with the TOS9300 series tester			
Indicators	CHANNEL	Indicates the setting of each channel with color. Red: High, Green: Low, Orange: Contact being checked, Off: Open			
maicators	EXTERNAL	Lights up when external control is on			
	POWER	Lights up when the power is on			

[Interface and other functions]

Item			TOS9320		
Control switch			EXTERNAL I/O switch for switching the following controls. ON: External control through the CONTROLLER INTERFACE OFF: Control from the TOS9300 series tester		
CONTROLLER INTERFACE (external control)		external control)	D-sub 25-pin connector.		
	Function		Sets each channel to high or low or all channels to open. Outputs the setting of each channel.		
			The input signals are all low-active control. The input terminal is pulled up to +12 V by a resistor. Leaving the input terminal		
			open is equivalent to applying a high level signal.		
		High-level input voltage	11 V to 15 V		
	Input	Low-level input voltage	0 V to 4 V		
		Low-level input current	-5 mA max.		
		Input time width	5 ms min.		
		Output method	Open collector output (4.5 Vdc to 30 Vdc)		
	0	Output withstanding voltage	30 Vdc		
	Output	Output saturation voltage	Approx. 1.1 V (25°C, 77°F)		
		Maximum output current	400 mA (TOTAL)		
TOS9300 series tester interface		e	MINI DIN 8-pin connector. Accuracy guaranteed up to 4 units (16 channels)		


[General specifications]


Item			TOS9320			
	Installation location	1	Indoors, 2000 m or less			
Environment	Spec guaranteed	Temperature	5°C to 35°C (41°F to 95°F)			
	range	Humidity	20%rh to 70%rh (no condensation)			
	Operating range	Temperature	0°C to 40°C (32°F to 104°F)			
		Humidity	20%rh to 80%rh (no condensation)			
	Storage range	Temperature	-20°C to 70°C (-4°F to 158°F)			
	Storage range	Humidity	90%rh or less (no condensation)			
Dawar aunah	Nominal voltage range (allowable voltage range)		100 Vac to 240 Vac (90 Vac to 250 Vac)			
Power supply	Power consumption		50 VA max.			
	Allowable frequence	y range	47 Hz to 63 Hz			
Insulation resist	ance (between AC LI	NE and chassis)	30 MΩ or more (500 Vdc)			
Withstanding vo	Itage (between AC L	INE and chassis)	1500 Vac for 1 minute, 20 mA or less			
Earth continuity			25 Aac/0.1 Ω or less			
Weight			Approx. 8 kg (17.6 lb)			
Accessories			Power cord (1 pc., length: 2.5 m: The attached power cord varies depending on the shipment destination.) High-voltage test lead [TL31-TOS] (8 red), Lead for high voltage parallelconnection TL33-TOS (1 pair), Interface cable (1 pc.), CONTROLLER INTERFACEplug (1 set), High-voltage warningsticker (2 pc.), Channel labels (For the panel (1 sheet), For the test leads (1 sheet)), User's manual (1 copy), Safety Information (1 copy)			
Electromagnetic compatibility *1 *2			Complies with the requirements of the following directive and standards. EMC Directive 2014/30/EU, EN 61326-1 (Class A *3), EN 55011 (Class A *3, Group 1 *4), EN 61000-3-2, EN 61000-3-3 Applicable under the following conditions The maximum length of all cabling and wiring connected to this product is less than 2.5 m. A shielded cable is used for the connection to the CONTROLLER INTERFACE. The high-voltage test lead TL31-TOS is in use. Electrical discharges are applied only to the EUT.			
Safety *1			Complies with the requirements of the following directive and standards. Low Voltage Directive 2014/35/EU *2, EN 61010-1 (Class I *5, Pollution Degree 2 *6), EN 61010-2-030			


- *1 Does not apply to specially ordered or modified products.
- *2 Only on models that have CE/UKCA marking on the panel.
- *3 This is a Class A instrument. This product is intended for use in an industrial environment. This product may cause interference if used in residential areas. Such use must be avoided unless the user takes special measures to reduce electromagnetic emissions to prevent interference to the reception of radio and television broadcasts.
- *4 This is a Group 1 instrument. This product does not generate and/or use intentionally radio-frequency energy, in the form of electromagnetic radiation, inductive and/or capacitive coupling, for the treatment of material or inspection/analysis purpose.
- *5 This is a Class I instrument. Be sure to ground this product's protective conductor terminal. The safety of this product is guaranteed only when the product is properly grounded.
- *6 Pollution is addition of foreign matter (solid, liquid or gaseous) that may produce a reduction of dielectric strength or surface resistivity. Pollution Degree 2 assumes that only non-conductive pollution will occur except for an occasional temporary conductivity caused by condensation.


External Dimensions (Unit:mm(inches))











High-Voltage Scanner

TOS9320



Dimensions(Maximum) / Weight

430(16.93")(440(17.32"))W×88(3.46")(105(4.13"))H× 370(14.57")(390(15.35"))Dmm/ 8 kg(17.6 lbs)

High-Voltage Scanner for TOS9300 Series for Multi-Channel Testing Systems

The high-voltage scanner TOS9320 is a specialized option for the TOS9300 series, capable of rapidly distributing test voltage from the main unit to multiple testing points for withstanding voltage and insulation resistance testing. Channels can be controlled with an external device through the back panel CONTROLLER INTERFACE connector. Remote control is not limited to the TOS9300 series, but is also compatible with previous models such as the TOS5300 series hipot/insulation resistance tester. The TOS9320 high-voltage scanner is an essential tool for the automation of highly reliable testing of electronic devices among multiple channels.

Features

- ■Output can be expanded to four channels with one high-voltage scanner. The electric potential of each channel can be arbitrarily set to high, low, or open, and can be tested at any of these four points.
- ■Up to four high voltage scanners (total 16 channels) can be connected to each unit.
- ■Output of each channel and contact with testing points can be easily monitored.

Remote Control Box

The remote control box can be used to start and stop withstanding voltage and insulation resistance tests. One model is for use with one hand, and the other model is for use with two hands.

RC01-TOS (One-hand operation/1.5 m)



*DD-5P/9P DIN conversion cable required for connection with TOS9300 series.

RC02-TOS (Two-hand operation/1.5 m)



*DD-5P/9P DIN conversion cable required for connection with TOS9300 series.

DIN Conversion Cable

The DIN (5 pin \to 9 pin) conversion cable is used for connection with the following optional products and the TOS9300 series.

- Remote control box(RC01-TOS/RC02-TOS)
- High voltage test probe(HP01A-TOS/HP02A-TOS)

DD-5P/9P Adaptor/DIN to Mini DIN



Multi Outlet

The multi outlet OT01-TOS can be used to connect to main plug standards world wide by connecting to the AC LINE OUT terminal block of the EUT power supply

OT01-TOS



Warning Light Unit

The warning light unit indicates when the TOS9300 is performing a test, making clear that a test is in progress from a distance.

PL02A-TOS (for DC24 V)



High-Voltage Test Probe

This probe is used for generating test voltage. This probe has been designed to only generate test voltage when the user operatates the probe with both hands in order to prevent accidental test voltage generation.

- HP01A-TOS (Max.AC4 kV DC5 kV/1.8 m)
- HP02A-TOS (Max.AC4 kV DC5 kV/3.5 m)



*DD-5P/9P DIN conversion cable required for connection with TOS9300 series.

Rack Mount Bracket

Complied Model	JIS Standard	EIA Standard		
Complied Wodel	Bracket Model Name	Bracket Model Name		
	KRB150-TOS	KRB3-TOS		
TOS9300 TOS9301 TOS9301PD TOS9302 TOS9303 TOS9303LC	KRB150-TOS THE STATE OF THE ST	KRBS-TOS OF THE STORY OF THE		
	KRB100-TOS	KRB2-TOS		
TOS9320	KRB100-TOS GROUP TO	KRB2-TOS GEORGE 31 GEORGE 31 GEORGE 32 Unit mm(inches)		

Others



High-Voltage Digital Voltmeter

- ●Measurement of high voltages (AC/DC) of up to 10 kV maximum ●Large 4 1/2 digit LED display
- •High measuring accuracy and input resistance
- ●Light weight of only 3 kg ●Compact design
- •Excellent ease of maintenance

149-10A



Specification			
Туре	Double integration type. (sampling cycle: 3 times/sec)		
DC Voltage	Measuring range: 0.500 kV to 10,000 kV Accuracy: $\pm (0.5~\%$ of reading + 0.03 % of range) Input resistance: 1000 M $\Omega \pm 2~\%$		
AC Voltage	Measuring range: 0.500 kV to 10,000 kV Accuracy: \pm (1 % of reading + 0.05 % of range) Frequency characteristics: 50/60 Hz (sine wave rms value display of mean value response) Input resistance: 1000 M Ω \pm 2%		
Power	100 V ±10%, Approx. 10 VA		
Dimensions (MAX)	134[5.27 inch]W × 164[6.46 inch]H × 270[10.63 inch]D mm (140[5.51 inch]W × 189[7.44 inch]H × 350[13.78 inch]D mm)		
Weight	Approx. 3 kg (6.6 lbs)		
Accessories	TL05-TOS High voltage test leads: 1 HTL2.5DH High voltage test lead: 1		

UL Resistance Load

This device is described in section 125, paragraph 2-1B1 of UL1492. The RL01-TOS is a variable load resistor for checking the output voltage of hipot testers used in dielectric strength testing on production lines. (Complies with UL regulations including UL1270, UL1409 and UL1410.)

RL01-TOS



Specification	
Resistors	120 k Ω / 159 k Ω / 210 k Ω / 279 k Ω / 369 k Ω / 489 k Ω / 648 k Ω / 858 k Ω / 1,137 k Ω / 1,500 k Ω / 1,989 k Ω / 2,148 k Ω
Resistance Accuracy	+1 %, -0 % of nominal value when set to 120 k Ω , ±1 % of nominal value when set to other values
Maximum Operating Voltag	1300 V (continuous rating)
Maximum Overload Voltage	1400 V for 5 seconds (application may not be repeated within 1 minute)
Dimensions (MAX)	200[7.87 inch]W × 100[3.94 inch]H × 260[10.24 inch]D mm (210[8.27 inch]W × 120[4.72 inch]H × 295[11.61 inch]D mm)
Weight	Approx. 2.6 kg (5.73 lbs)
Accessories	TL04-TOS High-voltage test lead: 2 TL05-TOS High-voltage test lead: 1

Calibration Resistor for Insulation Resistance Tester

The 929 Series Standard Resistors are for calibration of Insulation Testers.

- **929-1M (1 MΩ)**
- **929-10M (10 MΩ)**
- **929-100M (100 MΩ)**



Specification	
Nominal Resistance	1 MΩ(929-1M)/ 10 MΩ(929-10M) 100 MΩ(929-100M)
Accuracy of Resistance	1 % at 25 °C ±10 °C
Temperature Coefficient	100 ppm/°C or better
Voltage Coefficient	1 ppm/V or better
Working voltage rating	1.2 kV
Dimensions (MAX)	64[25.20 inch]W × 24[9.45 inch]H × 30[11.81 inch]D mm
	s standard resistors can not be installed

^{*}The 929 series standard resistors can not be installed directly to the TOS series. Please use the test lead for connection.

Lineup Overview

●Electrical Safety Multi-analyzer

	Test items						
Model	4	<u>4</u>	Ē.	© ©			
	AC Withstanding Voltage (AC Hipot)	DC Withstanding Voltage (DC Hipot)	Insulation Resistance	Earth Continuity (Ground Bond)	Leakage Current	Partial Discharge	
T0S9300	•		•				
T0S9301	•	•	•				
T0S9301PD	•	•	•			•	
T0S9302	•			•			
T0S9303	•	•	•	•			
T0S9303LC	•	•	•	•	•		

●Option

Description	Model	Remark			
High-voltage scanner	TOS9320	4 channel high-voltage scanner with contact check function; can be used standalone			
Remote control box	RC01-TOS	One-hand operation/1.5 m			
Remote Control box	RC02-TOS	Both-hands operation/1.5 m			
DIN conversion cable	DD-5P/9P	It is required when RC01-TOS/RC02-TOS, HP01A-TOS/HP02A-TOS and HP21-TOS is used			
High voltage toot puebe	HP01A-TOS	Max.AC4 kV • DC5 kV/1.8 m			
High-voltage test probe	HP02A-TOS	Max.AC4 kV • DC5 kV/3.5 m			
Warning light unit	PL02A-TOS	for DC24 V			
Multi outlet OT01-TOS		for TOS9303LC			
	KRB150-TOS	JIS standard (mm) for TOS9300/9301/9301PD/9302/9303/9303LC			
Dook mount brookst	KRB3-TOS	EIA standard (inch) for TOS9300/9301/9301PD/9302/9303/9303LC			
Rack mount bracket	KRB100-TOS	JIS standard (mm) for TOS9320			
	KRB2-TOS	EIA standard (inch) for TOS9320			









KIKUSUI ELECTRONICS CORPORATION

1-1-3, Higashiyamata, Tsuzuki-ku, Yokohama, Kanagawa, 224-0023, Japan Phone:(+81)45-593-0200, Facsimile:(+81)45-593-7591, https://global.kikusui.co.jp/

KIKUSUI AMERICA, INC. 1-310-214-0000 www.kikusuiamerica.com



3625 Del Amo Blvd., Suite 160 Torrance, CA90503 Phone: 310-214-0000, Facsimile: 310-214-0014

KIKUSUI TRADING (SHANGHAI) Co., Ltd. www.kikusui.cn Room 305, Shenggao Building, No.137, Xianxia Road, Shanghai City, China Phone: 021-5887-9067, Facsimile: 021-5887-9069

KIKUSUI ELECTRONICS EUROPE GmbH



Grossenbaumer Weg 8, 40472 Duesseldorf, Germany Phone: +49(211)54257600, E-mail: support@kikusui-europe.com

For our local sales distributors and representatives, please refer to "sales network" of our website

Distributor/Representative

■ All products contained in this catalogue are equipment and devices that are premised on use under the supervision of qualified personnel, and are not designed or produced for home-use or use by general consumers. ■ Specifications, design and so forth are subject to change without prior notice to improve the quality. ■ Product names and prices are subject to change and production may be discontinued when necessary. ■ Product names, company names and brand names contained in this catalogue represent the respective registered trade name or trade mark. ■ Colors, textures and so forth of photographs shown in this catalogue may differ from actual products due to a limited fidelity in printing. ■ Although every effort has been made to provide the information as accurate as possible for this catalogue, certain details have unavoidably been omitted due to limitations in space. ■ If you find any misprints or errors in this catalogue, it would be appreciated if you would inform us. ■ Please contact our distributors to confirm specifications, price, accessories or anything that may be unclear when placing an order or concluding a purchasing agreement.

Printed in Japan Issue:Mar.2025 2025030.2KPRIEC71